If you have any comments or concerns, please feel free to contact our customer service department at:

Toll-free: 1-800-835-0438

OR

Email: info@gofia.com

SEAT COVERS

**FEATURING** 

SUPER-GRIP® THE SLIP RESISTANT FASTENING SYSTEM

INSTALLATION INSTRUCTIONS **FOR** TR48-23, OE38-23, SL68-23, SP88-23

Thank you for purchasing one of our fine quality products. Your seat cover is engineered from high quality materials and designed with precision to give you a long-lasting, well-adjusted fit.

# **INSTRUCTIONS:**

# BACKREST COVER - BUCKETS / "40" PORTION X 2:

- 1) Remove head rest (see note)
- 2) Slip cover over backrest

4) Adjust Velcro to equalize tension

4) Adjust straps and buckles to equalize tension

- 5) Replace headrests (see note)
- 3) Tuck flaps under backrest and attach to Velcro at back

# B) CUSHION COVER - BUCKETS / "40" PORTION X 2:

- 1) Center cover on the seat
- 2) Pass the front strap under seat. Buckle to back flap
- 3) Pass side straps through the opening between the molded plastic
- and the seat. Buckle to back flap

#### **BACKREST COVER - "20" PORTION:** C)

- 1) Slip cover over armrest so armrest is covered when in up position. (top of armrest in down position is not covered).
- 2) Snug cover at back of armrest so the velcro on cover is positioned through the crevice where lid and armrest are hinged
- 3) Open armrest/console lid and position adhesive back velcro (supplied) to align with velcro on cover
- 4) Snug cover at front of armrest and position adhesive back velcro tabs(supplied) to the inside well of cup holder
- 5) Snug both sides of the cover and position adhesive back velcro (supplied) inside armrest/console
- 6) Secure all velcros

### **CUSHION/COMPARTMENT COVER- "20" PORTION:**

1) Open lid

2) Slip cover over lid, pull down firmly and velcro at bottom of cover

# **NOTES:**

## 1) SELF-LOCKING SUPER-GRIP® BUCKLE:



## 3) RE-INSTALLATION OF HEADRESTS

- A) Ensure pre-cut holes in seat cover align with holes in headrest base.
- B) Replace headrests

## 2) HEAD REST REMOVAL:

A) - Insert paper clip into holes at base to release - Lift off

OR

- B) Push in side release buttons
  - Lift off

(If unable to remove consult dealership)



WARNING: NEVER INSTALL SEAT COVERS ON SEATS WITH BUILT-IN AIRBAGS AS THIS MAY INTERFERE WITH THE PROPER DEPLOYMENT OF THE AIR BAGS WHICH COULD RESULT IN SERIOUS INJURY.