

If you have any comments or concerns,  
please feel free to contact our  
customer service department at:  
Toll-free: 1-800-835-0438  
OR  
Email: info@gofia.com

**CUSTOM SEAT COVERS  
BY**



**FEATURING  
SUPER-GRIP® THE SLIP RESISTANT FASTENING SYSTEM**

**INSTALLATION INSTRUCTIONS  
FOR  
TR49-5, OE39-5, SP89-5**

Thank you for purchasing one of our fine quality products. Your seat cover is engineered from high quality materials and designed with precision to give you a long-lasting, well-adjusted fit. The **Super Grip Buckles** are self-locking. For proper usage, see diagram.

**INSTRUCTIONS:**

**A) BACKREST COVERS – “40” PORTIONS:**

- 1) Open zipper closure in seat cover
- 2) Install cover under seat belt
- 3) Close zipper (see note)
- 4) Tuck flap through crevice and attach to velcro at back
- 5) Adjust velcro to equalize tension

**B) CUSHION COVER - “40” PORTIONS:**

- 1) Center cover on the seat
- 2) Pass the front strap under seat and buckle
- 3) Pass side straps around back of seat and buckle
- 4) Adjust straps and buckles to equalize tension

**C) CUSHION COVER – “20” PORTION:**

- 1) Center cover on the seat
- 2) Tuck the back part of cushion cover through seat crevice
- 3) Pass the front straps under the seat and secure to center buckle
- 4) Pass the side straps under back corners of center seat and secure to end buckles
- 5) Adjust straps and buckles to equalize tension

**D) BACKREST COVER – “20” PORTION:**

- 1) Open armrest / business console
- 2) Center cover under armrest
- 3) Position adhesive backed velcro (supplied) to align with the velcro on cover
- 4) Snug cover at back of armrest so that the velcro attached to cover meets the metal hinge
- 5) Secure the adhesive velcro to the hinge to align with velcro on cover

**NOTES:**

**1) SELF-LOCKING SUPER-GRIP® BUCKLE:**



**2) ZIPPER:**

- A) For ease in installation, the zipper is longer than the cover. Tuck excess zipper under cover.

**3) SEATS WITH RELEASE LEVERS AND POWER CONTROLS:**

- A) Locate levers or controls once seat cover is installed
- B) Slit hole(s) into the stretch fabric. **THE STRETCH FABRIC WILL NOT RUN**

**WARNING: NEVER INSTALL SEAT COVERS ON SEATS WITH BUILT-IN AIRBAGS AS THIS MAY INTERFERE WITH THE PROPER DEPLOYMENT OF THE AIR BAGS WHICH COULD RESULT IN SERIOUS INJURY.**

