



INSTALLATION INSTRUCTIONS

Congratulations – your new Work-Rite load assists are quality products capable of improving the handling and comfort of your vehicle while under load. As with all products, proper installation is the key to obtaining all of the benefits your kit is capable of delivering. Please take a few minutes to read through the instructions to identify the components and learn where and how they are used. It is a good idea to start by comparing the parts in your kit with the parts list below.

**NOTE: IF ANY PARTS ARE MISSING FROM THE KIT,
PLEASE CALL 1-800-888-0650.
PLEASE DO NOT CALL OR RETURN THE KIT TO THE DEALER.**

Be sure to take all applicable safety precautions during the installation of the kit. The instructions listed in this brochure and the illustrations all show the left, or driver's side of the vehicle. To install the right side assembly simply follow the same procedures.

STEP 1 – PREPARE THE VEHICLE

With the vehicle on a solid, level surface chock the front wheels. Remove the negative battery cable. Remove the jounce bumpers located under the frame rail. The jounce bumpers, bolts, and nuts will not be re-used with this kit.

STEP 2 – PRE-ASSEMBLE THE KIT

Select the left upper bracket (5633) and insert a 3/8"-16 x 3" carriage bolt into the square hole. **See Figure "A"**. Select one Work-Rite load assist and one spacer from your kit and attach it to the upper bracket using a 3/8"-16 x 1-1/2" hex head bolt and flat washer inserted through the bottom of the Work-Rite and into the small hole in the top, and through the spacer. Secure the Work-Rite and spacer to the upper bracket using a flange lock nut. **See Figure "A"**.

STEP 3 – INSTALLING THE ASSEMBLY ON THE VEHICLE

Attach the upper bracket onto the vehicle by inserting the 3/8"-16 x 3" carriage bolt into the hole on the bottom of the frame from the jounce bumper. Make sure the brake line bracket is also inserted onto the carriage bolt. **See Figure "A"**. Install a 3/8"-16 flange lock nut onto the carriage bolt and tighten. Next, install a 5/16"-24 x 1" hex head bolt and 5/16" washer into the hole on the outside leg of the upper bracket and through the existing hole on frame. Secure with a 5/16"-24 flange nut. **See Figure "A"**.

Repeat steps 1-3 for the right side of the vehicle.

STEP 4 – FINISH UP

Remove the wheel chocks and reconnect the battery cable. Now you're finished and ready to put your Work-Rite to use!

PARTS LIST

WORK-RITE LOAD ASSISTS	1260	2	5/16"-24 X 1" HEX BOLT	2
LEFT UPPER BRACKET	5633	1	3/8"-16 FLANGE LOCK NUT	4
RIGHT UPPER BRACKET	5634	1	5/16"-24 FLANGE LOCK NUT	2
SPACERS	0013	2	3/8" FLAT WASHERS	2
3/8"-16 X 1-1/2" HEX BOLT		2	5/16" FLAT WASHERS	2
3/8"-16 X 3" CARRIAGE BOLT		2		

FIGURE "A"

NOTE: Both illustrations are of the left, or drivers side, of the vehicle. Reverse any orientations when assembling and installing the right, or passenger side of the vehicle.

