



## **INSTALLATION INSTRUCTIONS**

Congratulations – your new Work-Rite load assists are quality products capable of improving the handling and comfort of your vehicle while under load. As with all products, proper installation is the key to obtaining all of the benefits your kit is capable of delivering. Please take a few minutes to read through the instructions to identify the components and learn where and how they are used. It is a good idea to start by comparing the parts in your kit with the parts list below.

**NOTE: IF ANY PARTS ARE MISSING FROM THE KIT,  
PLEASE CALL 1-800-888-0650.  
PLEASE DO NOT CALL OR RETURN THE KIT TO THE DEALER.**

Be sure to take all applicable safety precautions during the installation of the kit. The instructions listed in this brochure and the illustrations all show the left, or driver's side of the vehicle. To install the right side assembly simply follow the same procedures.

### **STEP 1 – PREPARE THE VEHICLE**

With the vehicle on a solid, level surface chock the front wheels. Remove the negative battery cable. Remove the jounce bumpers located under the frame rail. The jounce bumpers will not be re-used with this kit.

### **STEP 2 – MOUNTING THE WORK-RITE ON THE VEHICLE**

Select one Work-Rite load assist from your kit. Insert a 3/8"-16 x 3-1/4" bolt and flat washer through the bottom of the Work-Rite and into the small hole in the top. Place the upper mount over the bolt and on top of the Work-Rite. Insert the upper mount into the factory jounce bumper retainer. From the inside of the frame, place a large flat washer over the bolt, then install a 3/8"-16 flange nut. **See Figure "A"**.

**NOTE: An optional spacer may be installed to engage the Work-Rite sooner when a load is applied. To install, place between the Work-Rite and the upper bracket. If the spacers are installed, use the 3/8"-16 x 3-3/4" bolt instead of the 3/8"-16 x 3-1/4" bolt. There should be 1/4" to 3/8" between the Work-Rite and the axle. See Figure "A".**

### **STEP 3 – FINISH UP**

Remove the wheel chocks and reconnect the battery cable. Now you're finished and ready to put your Work-Rite to use!

## **PARTS LIST**

WORK-RITE LOAD ASSISTS	1264	2	3/8"-16 X 3-3/4" HEX BOLT	2
OPTIONAL SPACERS	0013	4	3/8"-16 FLANGE NUT	2
UPPER MOUNT	5663	2	FLAT WASHER	2
3/8"-16 X 3-1/4" HEX BOLT		2	LARGE FLAT WASHER	2

Figure "A"

