



## **INSTALLATION INSTRUCTIONS**

Congratulations – your new Work-Rite load assists are quality products capable of improving the handling and comfort of your vehicle while under load. As with all products, proper installation is the key to obtaining all of the benefits your kit is capable of delivering. Please take a few minutes to read through the instructions to identify the components and learn where and how they are used. It is a good idea to start by comparing the parts in your kit with the parts list below.

**NOTE: IF ANY PARTS ARE MISSING FROM THE KIT,  
PLEASE CALL 1-800-888-0650.  
PLEASE DO NOT CALL OR RETURN THE KIT TO THE DEALER.**

Be sure to take all applicable safety precautions during the installation of the kit. The instructions listed in this brochure and the illustrations all show the right, or passenger's side of the vehicle. To install the left side assembly, simply follow the same procedures.

### **STEP 1 – PREPARE THE VEHICLE**

With the vehicle on a solid, level surface chock the rear wheels. Remove the negative battery cable. Using a jack rated for your vehicle's weight, raise the front of the vehicle and remove the wheels. Lower the vehicle onto jack stands rated to support your vehicle. Remove the jounce bumpers located under the frame rail, by pulling them out of the jounce bumper cup. The jounce bumpers will not be re-used with this kit. **See Figure "A"**.

### **STEP 2 – INSTALLING THE WORK-RITE LOAD ASSIST**

Using a twisting motion, push the Work-Rite load assist bumper into the jounce bumper cup that is welded to the frame. **See Figure "A"**.

### **STEP 4 – FINISH UP**

Install the wheels and torque the lug nuts to the manufacturer's specifications. Remove the jack stands and lower the vehicle back to the ground. Remove the wheel chocks and reconnect the battery cable. Now you're finished and ready to put your Work-Rite to use!

## **PARTS LIST**

Description	Part Number	Qty.
WORK-RITE BUMPER	1263	4

Figure "A"

