



Holley Valve Cover P/N 241-80 Installation Instructions

NOTE: Please read the following instructions thoroughly and carefully before beginning the installation.

1. ALWAYS use Felpro® Ultrablue RTV sealant for cementing gaskets to valve covers or cylinder heads during installation.
2. Use one of the rubber grommets (supplied) for both the PCV valve and the air cleaner vent hose connection.
3. Use the PCV valve or vent hose fitting on the valve cover to add or replace oil in vehicles 1967 or later.
4. On vehicles (prior to 1967 with open-vent systems and oil fill tubes), use two Holley Breather Caps for the valve cover openings. See the Holley catalog listing for your application.

NOTE: Holley recommends using chrome T-bar valve cover bolts, P/N 241-201.

199R-10286
Date: 2-27-02



Holley Valve Cover P/N 241-80 Installation Instructions

NOTE: Please read the following instructions thoroughly and carefully before beginning the installation.

1. ALWAYS use Felpro® Ultrablue RTV sealant for cementing gaskets to valve covers or cylinder heads during installation.
2. Use one of the rubber grommets (supplied) for both the PCV valve and the air cleaner vent hose connection.
3. Use the PCV valve or vent hose fitting on the valve cover to add or replace oil in vehicles 1967 or later.
4. On vehicles (prior to 1967 with open-vent systems and oil fill tubes), use two Holley Breather Caps for the valve cover openings. See the Holley catalog listing for your application.

NOTE: Holley recommends using chrome T-bar valve cover bolts, P/N 241-201.

199R-10286
Date: 2-27-02



Holley Valve Cover P/N 241-80 Installation Instructions

NOTE: Please read the following instructions thoroughly and carefully before beginning the installation.

1. ALWAYS use Felpro® Ultrablue RTV sealant for cementing gaskets to valve covers or cylinder heads during installation.
2. Use one of the rubber grommets (supplied) for both the PCV valve and the air cleaner vent hose connection.
3. Use the PCV valve or vent hose fitting on the valve cover to add or replace oil in vehicles 1967 or later.
4. On vehicles (prior to 1967 with open-vent systems and oil fill tubes), use two Holley Breather Caps for the valve cover openings. See the Holley catalog listing for your application.

NOTE: Holley recommends using chrome T-bar valve cover bolts, P/N 241-201.

199R-10286
Date: 2-27-02