



41195 - Vehicle Wiring Installation Instructions
Chevrolet Caprice Estate Wagon 1991 – 1996
Buick Roadmaster Estate Wagon 1991 – 1996
Oldsmobile Custom Cruiser 1991 – 1992

1. Open the tailgate and remove the plastic trim panels from both the driver's and passenger's side of the vehicle to locate the taillight wiring harnesses.
2. On the Driver's side, disconnect the vehicle wiring harness from the taillight socket. Plug the Hopkins® T-Connector end with the yellow wire in-between the mating plugs on the passenger's side taillight socket and vehicle wiring harness.
3. On the driver's side, route the T-Connector end with the green wire to the passenger's side along the threshold. Plug the Hopkins T-Connector end with the green wire in-between the mating plugs on the passenger's side taillight socket and vehicle wiring harness. Route the green wire underneath the rubber strip that is pressed in the top of the tailgate threshold.
4. Route the wire with the 4-flat connector to near center of the rear door.
5. Locate a suitable grounding point on the vehicles frame for the ring terminal on the white wire which is attached to the 4-way flat connector. Clean dirt, paint and rust proofing from area. Drill a 3/32" hole and secure white wire with ring terminal using self tapping screw (provided). Verify what is behind any surface prior to drilling to avoid damage to the vehicle. Do not drill into the vehicle or any exposed surfaces.
6. Reinstall the trim panels and any other items removed during installation. Be careful to avoid any areas that could cut or pinch the wires.
7. Route the 4-way flat harness to either side of the receiver hitch and secure it with ny-ties.
8. Attach the 4-way flat dust cover (provided) to the 4-way flat connector.
9. Apply a small amount of grease (provided) to the 4-way flat terminals to prevent corrosion.
10. Plug completed wire harness into the trailer 4-way flat connector.
11. Test all functions with the engine running to ensure proper operation.

TIPS:

Grease applied to the wiring terminals on a regular basis will help prevent corrosion.

Always unplug boat trailer connector before backing trailer into the water.

Need Help? (English Only)
1-800-835-0129
techsupport@hopkinsmfg.com
www.hopkinstowingsolutions.com