



41265 - Vehicle Wiring Installation Instructions Chevrolet Equinox 2007-09 (4-Way Flat)

1. Locate the vehicle plug near spare tire at rear of vehicle.
2. Remove the cap or plug from the vehicle harness.
3. Plug the Hopkins® vehicle harness plug into the socket and route the 4-way flat to either side of the receiver hitch and secure it with ny-ties.
4. Attach the 4-way flat dust cover (provided) to the 4-way flat connector.
5. Apply a small amount of grease (provided) to the 4-way flat terminals to prevent corrosion.
6. Plug completed wire harness into the trailer 4-way flat connector.
7. Test all functions with the engine running to ensure proper operation.

TIPS:

Grease applied to the wiring terminals on a regular basis will help prevent corrosion.

Always unplug boat trailer connector before backing trailer into the water.

Need Help? (English Only)
1-800-835-0129
techsupport@hopkinsmfg.com
www.hopkinstowingsolutions.com