



## **41825 - Vehicle Wiring Installation Instructions Toyota Highlander (w/Tow Package) 2008-13 (4-Way Flat )**

1. Locate the vehicle plug near spare tire at rear of vehicle.
2. Remove the cap or plug from the vehicle harness.
3. Plug the Hopkins® vehicle harness plug into the socket and route the 4-way flat to either side of the receiver hitch and secure it with ny-ties.
4. Attach the 4-way flat dust cover (provided) to the 4-way flat connector.
5. Apply a small amount of grease (provided) to the 4-way flat terminals to prevent corrosion.
6. Plug completed wire harness into the trailer 4-way flat connector.
7. Test all functions with the engine running to ensure proper operation.

### **TIPS:**

Grease applied to the wiring terminals on a regular basis will help prevent corrosion.

Always unplug boat trailer connector before backing trailer into the water.

**Need Help? (English Only)**  
**1-800-835-0129**  
**techsupport@hopkinsmfg.com**  
**www.hopkinstowingsolutions.com**