



## **41855 - Vehicle Wiring Installation Instructions**

### ***Toyota 4-Runner 2010 Adapter Harness***

1. Locate the (2) vehicle wiring harness plugs at the rear of vehicle above the factory 7- Way RV socket assembly. This connector harness will have the same connector ends as the Hopkins® Adapter Harness.
2. Disconnect the vehicle wiring harness plugs (2). Connectors can be disconnected by pressing or lifting on a locking tab and pulling apart.
3. Remove the factory adapter harness from the factory 7-way socket by pressing or lifting on a locking tab to disconnect it.
4. Note: If you wish to replace the existing factory 7-way socket connector purchase the Hopkins Multi-Tow #40955 (sold separately).
5. Insert the Adapter Harness into the rear of the existing factory 7-way making sure the connector is fully inserted and locked.
6. Route the wire harness to the (2) vehicle plugs. Connect the plugs and make sure the connectors are fully inserted and locked.
7. Plug trailer connector into the factory 7-way receptacle and test all functions with the engine running to ensure proper operation.

#### **TIPS:**

Grease should be applied to the wiring terminals on a regular basis to help prevent corrosion.

A heavy duty flasher may be required to eliminate rapid flashing.

Always unplug boat trailer connector before backing trailer into the water.

**Need Help? (English Only)**  
**1-800-835-0129**  
**techsupport@hopkinsmfg.com**  
**www.hopkinstowingsolutions.com**