



41875 - Vehicle Wiring Installation Instructions
Lexus RX 300 & Toyota Highlander w/tow 2001-2003 (4-Way Flat)
Lexus LX 470 w/tow 2001-2007 (4-Way Flat)

1. Locate the tow vehicle's trailer harness connector. It is located under the vehicle, behind the bumper, on the drivers side of the vehicle. On some vehicles the tow plug will be hidden under a black box, remove the 10 mm hex bolts and temporarily remove cover to reveal the tow plug.
2. Plug the Hopkins® vehicle harness plug into the socket and route the 4-way flat to either side of the receiver hitch and secure it with ny-ties.
3. Attach the 4-way flat dust cover (provided) to the 4-way flat connector.
4. Apply a small amount of grease (provided) to the 4-way flat terminals to prevent corrosion.
5. Plug completed wire harness into the trailer 4-way flat connector.
6. Test all functions with the engine running to ensure proper operation.
7. Re-install anything removed during installation.

TIPS:

Grease applied to the wiring terminals on a regular basis will help prevent corrosion.

Always unplug boat trailer connector before backing trailer into the water.

Need Help? (English Only)
1-800-835-0129
techsupport@hopkinsmfg.com
www.hopkinstowingsolutions.com