



41945 - Vehicle Wiring Installation Instructions ***Lexus RX 350 & RX 450 w/tow 2010 (4-Way Flat)***

1. Locate the tow vehicle's trailer harness connector. It is located under the vehicle, behind the bumper, on the driver's side of the vehicle.
2. Remove the cap or plug from the vehicle harness.
3. Plug the Hopkins® vehicle harness plug into the socket and route the 4-way flat to either side of the receiver hitch and secure it with ny-ties.
4. Attach the 4-way flat dust cover (provided) to the 4-way flat connector.
5. Apply a small amount of grease (provided) to the 4-way flat terminals to prevent corrosion.
6. Plug completed wire harness into the trailer 4-way flat connector.
7. Test all functions with the engine running to ensure proper operation.

TIPS:

Grease applied to the wiring terminals on a regular basis will help prevent corrosion.

Always unplug boat trailer connector before backing trailer into the water.

Need Help? (English Only)
1-800-835-0129
techsupport@hopkinsmfg.com
www.hopkinstowingsolutions.com