



1. Open trunk door and unscrew the T-nuts that hold the trunk liner to the taillight area.
2. Remove the center section molding by pulling the tab center retainers straight out with needle nose pliers. Use a flat blade screwdriver to pry up the molding tabs. Pull the trunk liner away from the taillight housings on each side of the vehicle to expose the two plug assemblies needed to attach the Wiring Kit.
3. Lift the locking tab on the driver's side plug assembly and pull apart. Connect the yellow wire plug assembly into each of the detached plugs.
4. Lift the locking tab on the passenger side plug assembly and pull apart. Route the green wire plug assembly behind the trunk liner and plug in to each of the detached plugs.
5. Test all functions to ensure proper installation. Secure the vehicle connector to the vehicle with a wire tie. Reinstall the trunk liner and route the 4-wire flat extension out under the trunk lid opening.
6. Apply grease to the wire harness trailer end to prevent corrosion.

NOTE: Always unplug trailer connection before backing into water.

-
1. Abra la puerta del baúl y destornille las tuercas en T que sujetan el forro del baúl al área de las luces traseras.
 2. Retire el molde de la sección del centro al halar los retenedores de lengüeta directamente hacia fuera con alicates de punta delgada. Use un destornillador de punta plana para levantar las lengüetas del molde. Hale el forro del baúl lejos de las cajas de las luces traseras en cada lado del vehículo para exponer los dos ensamblajes de enchufe necesarios para conectar el.
 3. Levante la lengüeta de cierre en el ensamblaje del enchufe del lado del conductor y separe. Conecte el ensamblaje de enchufe amarillo dentro de cada uno de los enchufes desconectados.
 4. Levante la lengüeta de cierre en el ensamblaje del enchufe del lado del pasajero y separe. Corra el ensamblaje de enchufe verde detrás del forro del baúl y enchufe dentro de los enchufes desconectados.
 5. Pruebe todas las funciones para asegurar la instalación apropiada. Asegure el conector de vehículo con un amarre de cable. Reinstale el forro del baúl y corra la extensión plana de 4 cables hacia fuera y debajo de la abertura de la tapa del baúl.
 6. Aplique grasa al extremo del arnés de cable del para prevenir la corrosión.

NOTA: Siempre desenchufe la conexión del remolque antes de dar la reversa hacia el agua.