

# OPTIONAL ALUMINUM COVER (PT. 130 0041) (PT. 130 0045)

## NOTE

The various protrusions on the shifter inhibit straight forward installation of cover onto shifter. Please follow instructions to avoid frustration.

## INSTALLATION

Remove knob from shifter. Move stick to neutral. Lower cover over stick. Turn the cover carefully to allow the opening to clear the Reverse Loc-out knob at the front and the upper cap screw on the stick. Rotate cover toward the right and move forward over the cable mount. Cover should now drop into position. Install quick release pins.

## REMOVAL

Remove knob. Remove quick release pins. Cover should be lifted and moved slightly to the rear to clear front cable bracket. Rotate cover to clear Reverse Loc-out knob. Tilt cover to clear screws on stick and lift cover free.

Early shifter frames fit the aluminum enclosure. Later design frames require that the opening in the enclosure be enlarged as shown below to the left. The later shifter frame has a support and a welded seam on this right front end.

## OPTIONAL

IF SHIFTER IS FASTENED DIRECTLY TO FLOOR (QUICK-RELEASE PLATE IS NOT USED)—REFER TO SECTIONED DRAWING BELOW.

