

Thank you for selecting a WeatherBeater® Floor Liner from Winfield Consumer Products. Your new front floor liners are custom molded to fit your Hyundai Santa Fe. The liners are made to take the place of your factory floor mats. *For correct fit, it is necessary to remove the factory floor mats before installing your new floor liners*. *However, do not remove the factory-installed carpeting.* 

Your liners are made from an engineering resin that is lightweight and extremely tough and durable. The easiest way to clean your liners is with a damp cloth or sponge. If using a cleaner, 409<sup>®</sup> or Glass Plus<sup>®</sup> work well. Use of Armor All<sup>®</sup>, Son-of-a-Gun<sup>®</sup> or similar items is discouraged as these products make the liners slick.

## INSTALLATION INSTRUCTIONS FOR YOUR HYUNDAI SANTA FE FRONT FLOOR LINERS





LEFT OR DRIVER'S SIDE

RIGHT OR PASSENGER'S SIDE

TO EASE INSTALLATION OF YOUR NEW FRONT LINERS, MOVE BOTH FRONT ROW SEATS ALL THE WAY BACK SO AS TO ALLOW THE MOST LEG ROOM. ONCE YOU HAVE INSTALLED YOUR LINERS, REPOSITION THE FRONT SEATS AS DESIRED.

NOTE THAT THE AREA ABOVE THE FUEL DOOR RELEASE LEVER ON THE DRIVER'S SIDE LINER IS LOWERED. THIS LOWERED AREA CAN BE TRIMMED AWAY TO ALLOW ACCESS TO THE FUEL RELEASE LEVER WITH THE LINER IN PLACE. A UTILITY KNIFE WORKS WELL FOR TRIMMING. YOU CAN ALSO JUST LIFT THE LINER UP TO ACCESS THE RELEASE.



Thank you for selecting a WeatherBeater<sup>®</sup> Floor Liner from Winfield Consumer Products. Your new rear floor liner is custom molded to fit your Hyundai Santa Fe. The liner is made to take the place of your factory floor mats. *For correct fit, it is necessary to remove the factory floor mat before installing your new floor liners*. *However, do not remove the factory-installed carpeting.* 

Your liner is made from an engineering resin that is lightweight and extremely tough and durable. The easiest way to clean your liner is with a damp cloth or sponge. If using a cleaner, 409<sup>®</sup> or Glass Plus<sup>®</sup> work well. Use of Armor All<sup>®</sup>, Son-of-a-Gun<sup>®</sup> or similar items is discouraged as these products make the liners slick.

## INSTALLATION INSTRUCTIONS FOR YOUR HYUNDAI SANTA FE SECOND SEAT FLOOR LINER

FRONT OF



TO EASE INSTALLATION OF YOUR 2<sup>nd</sup> SEAT SANTA FE FLOOR LINER, FIRST MOVE THE FRONT SEATS TO THEIR MOST FORWARD POSITIONS. WITH THIS DONE, INSERT LINER IN VEHICLE THEN REPOSITION THE FRONT SEATS AS DESIRED.