

Instructions for #6302 ATV Wiring Harness for 2 - 35 watt Lights

Wiring Your Lights...

- 1. Find a suitable flat surface that has an open space behind (like the fairing), drill a 1/2" hole and mount the switch.
- 2. Remove the fuse from the red wire.
- Plug the red and black wire set into the appropriate red and black wires on the light furthest (#1) from the switch. (see diagram)
- 4. Cut the terminals off of light #2. As you run the wire set past light #2, attach light #2 red and black wires using the enclosed wire splices.
- Continue routing the red harness wire back to the switch and plug it into one of the switch wires.
- 6. Attach the fused red wire to the other switch wire and route it back to the positive (+) battery terminal.
- 7. Route the black wire back to the battery and attach to the negative (-) post or other suitable ground.
- 8. Use the enclosed wire ties and protective tubing as needed to secure and protect the wiring.
- 9. Replace the fuse in the red wire and test your lights.
- 10. Adjust lights as needed.
- 11 YOUR DONE!

IF YOU HAVE ANY PROBLEMS OR QUESTIONS, PLEASE CALL CUSTOMER SERVICE AT 800-528-0950

