



INSTALLATION INSTRUCTIONS

Part Number: 33-2011

This filter fits: SEE CATALOG FOR CURRENT APPLICATIONS

* **FREE K&N® decal** To register your warranty, please see us online at knfilters.com/register. **FREE K&N® decal ***
Congratulations, you have purchased the finest air filter that money can buy. With proper care, this filter will last 1 million miles or more. This filter is a direct replacement for the stock air filter, and no modification will be required. However the following procedures **MUST** be followed to ensure the proper fit and seal of the K&N® air filter.

INSTALLATION:

1. Remove OE Filter from air box. Fig. 1
2. Clean all sealing surfaces free of dust and debris. Fig. 2
3. Install K&N® filter into air box. **NOTE: The filter is engraved with “This side up”, when installed correctly the engravings will be facing upward into the air box on the right side under the intake inlet of the OE air box lid.** Fig. 3 & 4
4. Close and fasten lid.
5. With the K&N® air filter installed, clean an area on the airbox and apply the K&N® Stop Decal. The decal will help notify others that this is a re-usable cabin filter.

THESE INSTRUCTIONS MUST BE FOLLOWED EVERY TIME THE FILTER IS SERVICED, OTHERWISE THE FILTER MAY NOT SEAL, AND DAMAGE TO THE ENGINE COULD RESULT.



Fig. 1



Fig. 2



Fig. 3



Fig. 4