

Zenith and Pierburg 28 Carburetors Instruction Sheet A2054-24

Remove the original Air Filter Case. If there is a small bore pipe leading to the Air Filter Case, block this off at source (Carburettor or Manifold). Large bore breather pipes can be fitted directly into the K&N base plate by drilling a suitably sized hole. If your model has a centre screw pillar, this must be removed. Remove any old gaskets and fit the 'O' Ring and base plate, securing it with 3 retaining clips. The shakeproof washers must be used.