



Part Number 57-0366

INSTALLATION INSTRUCTIONS

BMW 320i 2.0L 1998-2000 BMW 320i 2.2L 2000-2005
 BMW 320Ci 2.2L 2000-2005 BMW 323i 2.5L 1998-2000
 BMW 323Ci 2.5L 1999-2000 BMW Z3 2.0L 1999-2000

BMW 325i/325Ci/325Ti/325Xi 2.5L 2001-2005
 BMW 328i/328Ci 2.8L 1999-2000

1. Remove the 2 air box mounting bolts, unclip the mass air sensor (MAS) and remove the air box assembly from the car. (Fig. 1)
2. Remove the harness plug from the MAS, unclip & remove the MAS from the intake hose. (Fig. 2)
3. Remove the electrical harness-mounting bolt. (Fig. 3)
4. Attach the new mounting bracket to the harness mounting point using the allen head bolt & flat washer supplied. (Fig. 4)
5. Fit the saddle bracket to the new bracket using the countersunk screw, conical washer, flat washer and M6 nut supplied, exchange the standard hose clip for the new clip supplied. (Fig. 5)
6. Refit the MAS assembly to the intake hose and reconnect the electrical plug. (Fig. 6)
7. Fit the new Air filter to the airflow meter ensuring K&N logo is straight and fully tighten the clip. (Fig. 7)
8. Taking the necessary safety precautions as per manufacturers instructions carefully raise the front of the vehicle.
9. Carefully expand the flexi cold air hose & Pierce/drill 2 holes in one of the the plastic ends, feed the flexi cold air hose up the side of the radiator and secure approximately 4" / 10cm away from the Air filter. (Fig. 8) (*Note: Ensure the flexi cold air hose does not touch the engine pulleys*)
10. Ovalise & secure the pierced end of the cold air hose to the lower spoiler with 2 plastic ties supplied. (Fig. 9)
11. Secure the cold air hose to the radiator cowling as shown using a plastic tie supplied. (Fig. 10)
12. Carry out a final check of the height / alignment of the K&N induction system before starting the engine. Installation is now complete.

Parts list:

- 1 x Air filter.
- 1 x #60 Filter Hose Clip.
- 1 x Cold Air Hose Assembly.
- 1 x Literature Pack.
- 1 x Fixing Kit :-
 - 1 x M6 Nylock Nuts.
 - 1 x M6x20mm Allen Bolt.
 - 1 x M6x20mm c/sunk Bolt.
 - 4 x Long Plastic Ties.
 - 1 x Mounting Bracket.
 - 2 x Flat Washers.
 - 1 x #48 Hose Clip.
 - 1 x Saddle Bracket.
 - 1 x Conical Washer.

WARNING: Before starting the engine carry out a final fitment check of the K&N performance kit. It will be necessary for all intake systems to be checked periodically for realignment, clearance and tightening of all connections. Failure to follow the above instructions or proper maintenance may void the warranty.

FILTER MAINTENANCE: K&N suggests checking the filter periodically for excessive dirt build-up. When the element becomes covered in dirt (or once a year), service it according to the instructions on the Recharger service kit available from your K&N dealer, part number 99- 5003EU.

For cleaning instructions please visit our website: www.knfilters.com/cleaning



Fig. # 1



Fig. # 2



Fig. # 3



Fig. # 4



Fig. # 5



Fig. # 6



Fig. # 7



Fig. # 8



Fig. # 9



Fig. # 10