

LAKEWOOD STRUT TOWER BRACE INSTALLATION INSTRUCTIONS PART NO. 39000 2010 CAMARO SS MODELS

Thank you for your purchase from Lakewood Industries. For technical assistance, please call 216-688-8300 Monday thru Friday 8:30 AM to 5:00 PM EST.

WARNING: DUE TO THE TECHNICAL NATURE OF THIS PRODUCT, AND SPECIALIZED EQUIPMENT, PROFESSIONAL INSTALLATION IS RECOMMENDED. CAUTION: INSTALLATION OF THIS PRODUCT REQUIRES WORKING UNDER THE VEHICLE. IT IS THE RESPONSIBILITY OF THE INSTALLER TO ENSURE A SAFE WORKING ENVIRONMENT. THE USE OF AN AUTOMOTIVE LIFT IS RECOMMENDED. MAKE SURE THAT THE VEHICLE IS SAFELY SUPPORTED AND ALWAYS USE JACK STANDS. ALWAYS WEAR SAFETY GLASSES.

- 1. Safely raise and secure front of the vehicle. Always use jack stands.
- 2. Remove the front wheel/tires. NOTE: Removal of the struts is NOT required
- 3. Underhood; remove the nut and plate that secures the strut in the strut tower.
- 4. Place the alignment rings around the strut mounting stud, and position the strut tower brace on the vehicle.
- 5. Using the strut tower brace as a template, use a center punch to mark the center for each mount hole for the strut tower brace.

- 6. Use a 25/64" bit to drill the 4 mounting holes per strut tower.
- 7. Remove the alignment rings, and install the spacers over the strut studs, reposition the strut tower brace on the vehicle, and reinstall the strut mount plate and nut.
- 8. Install the mounting bolts, nuts, and washers.
- 9. Torque all of the 3/8" fasteners to 25 ft-lbs and torque the factory mount nut
- 10. Reinstall the wheel and tires and safely lower the vehicle.

Go to: www.prestoliteperformance.com to see a video installation of this product.

LAKEWOOD CHASSIS AND SUSPENSION PRODUCTS ARE ENGINEERED AND MANUFACTURED TO IMPROVE THE PERFORMANCE OF YOUR VEHICLE. WE ENCOURAGE YOU TO ENJOY USING OUR PRODUCTS SAFELY AT A SANCTIONED RACING FACILITY. PLEASE OBEY ALL TRAFFIC LAWS.



LAKEWOOD IS A TRADEMARK OF PRESTOLITE PERFORMANCE 10601 MEMPHIS AVE #12, CLEVELAND, OH 44144 216.688.8300 FAX 216.688.8306 FORM 97146776 08/10 Made in U.S.A. Printed in U.S.A.