



## LAKEWOOD STRUT TOWER BRACE INSTALLATION INSTRUCTIONS PART NO. 39001 2008 – 2010 DODGE CHALLENGER RT

Thank you for your purchase from Lakewood Industries. For technical assistance, please call 216-688-8300 Monday thru Friday 8:30 AM to 5:00 PM EST.

**WARNING: DUE TO THE TECHNICAL NATURE OF THIS PRODUCT, AND SPECIALIZED EQUIPMENT, PROFESSIONAL INSTALLATION IS RECOMMENDED.**

**CAUTION: INSTALLATION OF THIS PRODUCT REQUIRES WORKING UNDER THE VEHICLE. IT IS THE RESPONSIBILITY OF THE INSTALLER TO ENSURE A SAFE WORKING ENVIRONMENT. THE USE OF AN AUTOMOTIVE LIFT IS RECOMMENDED. MAKE SURE THAT THE VEHICLE IS SAFELY SUPPORTED AND ALWAYS USE JACK STANDS. ALWAYS WEAR SAFETY GLASSES.**

1. Remove the factory plastic strut tower caps
2. Loosen and remove the 3 strut mount nuts on each strut tower
3. Position the strut tower brace with the offset facing the front of the vehicle and lower the brackets down over the strut mount studs
4. Reinstall the nuts removed in step 2
5. The factory strut tower caps will require some trimming with tin snips or a dremel tool to clear the strut tower brace brackets.
6. After trimming the strut tower cap, reinstall on the mount studs.

Go to: [www.prestoliteperformance.com](http://www.prestoliteperformance.com)  
to see a video installation of this product.

**LAKEWOOD CHASSIS AND SUSPENSION PRODUCTS ARE ENGINEERED AND MANUFACTURED TO IMPROVE THE PERFORMANCE OF YOUR VEHICLE. WE ENCOURAGE YOU TO ENJOY USING OUR PRODUCTS SAFELY AT A SANCTIONED RACING FACILITY. PLEASE OBEY ALL TRAFFIC LAWS.**



LAKEWOOD IS A TRADEMARK OF PRESTOLITE PERFORMANCE  
10601 MEMPHIS AVE #12, CLEVELAND, OH 44144  
216.688.8300 FAX 216.688.8306

FORM 97146777  
08/10  
Made in U.S.A.  
Printed in U.S.A.