



# INSTALLATION INSTRUCTIONS

## Qwik Links - Part No. 21200, 21201, 21202

Thank you for your purchase from Lakewood Industries. For technical assistance, please call 216-688-8300 Monday thru Friday 8:30 AM to 5:00 PM EST.

**WARNING: DUE TO THE TECHNICAL NATURE OF THIS PRODUCT, AND SPECIALIZED EQUIPMENT, PROFESSIONAL INSTALLATION IS RECOMMENDED.**

**CAUTION: INSTALLATION OF THIS PRODUCT REQUIRES WORKING UNDER THE VEHICLE. IT IS THE RESPONSIBILITY OF THE INSTALLER TO ENSURE A SAFE WORKING ENVIRONMENT. THE USE OF AN AUTOMOTIVE LIFT IS RECOMMENDED. MAKE SURE THAT THE VEHICLE IS SAFELY SUPPORTED AND ALWAYS USE JACK STANDS. ALWAYS WEAR SAFETY GLASSES.**

### STEP 1

Properly raise and secure vehicle on either a drive-on automotive lift or place front wheels on ramps which are positioned on a level plane to prevent front suspension from being unevenly loaded side to side.

### STEP 2

Note position of anti-roll bar links in relationship to vehicle mounting points as Qwik Links will be installed in an identical manner onto vehicle.

### STEP 3

Remove O.E. anti-roll bar links.

### STEP 4

Install Qwik Link studs to vehicle mounting points and position for ease of removal and installation of hairpin cotter. Fully tighten stud into place.

### STEP 5

Install jam nuts on rod ends until bottoming and install one RH thread and one LH thread rod end onto link until bottoming.

### STEP 6

Adjust length by turning linkage rod while rod ends remain stationary until proper length is achieved and link installs onto studs.

### STEP 7

Install outer sleeve onto stud with chamber against rod end and then install hairpin cotter to secure link in place. Tighten rod end jam nuts.

**NOTE: To preload sway bar, loosen jam nuts and adjust linkage rod length accordingly then tighten jam nuts back into place.**

**NOTE: To remove end links, pull cotter pins and slide end links off the mount studs. For best results, park vehicle on an even surface to remove or install end links.**

**WARNING: Reinstallation of end links is required for safe operation on public highways.**



LAKEWOOD IS A TRADEMARK OF PRESTOLITE PERFORMANCE  
10601 MEMPHIS AVE #12, CLEVELAND, OH 44144  
216.688.8300 FAX 216.688.8306

FORM 97120200  
04/11