Care and Cleaning

To keep your billet grille looking their best, we recommend using only mild soap and water and a soft cotton cloth to wash and dry it. Use of rough cleaning agents or cloths may scratch or dull your billet grille.

Should your billet grille become scratched or dull, we recommend TRENZ® Metal Polish to bring back the mirror finish. There are three grades of TRENZ® Metal Polish (Coarse, Medium and Fine) that will help you keep your billet grille looking brand new. Select the TRENZ® Metal Polishes best for your needs:

- 1. Course (Red) Polish For severe scratches and pitted problems.
- 2. Medium (Green) Polish For light scratches and dulling problems.
- 3. Fine (White) Polish To bring back the mirror finish.

TRENZ® Metal Polish can be used on all metal products, including aluminum, stainless steel, brass and copper. If you have additional questions or concerns on the maintenance of your Lund® billet grille, please call us at 800-328-5863. You may also use high quality commercially available polish recommended for aluminum accessories.

Congratulations!

You have purchased one of many quality Lund® branded products offered by Lund International, Inc. We take the utmost pride in our products and want you to enjoy years of satisfaction from your investment. We have made every effort to ensure that your product is top quality in terms of fit, durability, finish and ease of installation.



Lund International, Lund Accessories Division 775 Tipton Industrial Drive, Building 2, Suite F Lawrenceville, GA 30045

Phone 800-328-5863 • Fax 800-782-5448 • Visit us at lundinternational.com

© 2005 Lund International, Inc. All rights reserved. Lund® and the Lund® logo are trademarks of Lund International, Inc.

Page 4 of 4





Installation Instructions

Part Number 84117 I-sheet Rev. A2



For proper installation and best possible fit, please read all instructions BEFORE you begin. For technical assistance or to obtain missing parts, please call Customer Relations at 1-800-328-5863.

Important Safety Information




CAUTION PRECAUCIÓN ATTENTION


To avoid risk of personal injury or property damage:

- Wear safety glasses and gloves while installing billet inserts.
- Use caution when working with any power tools.
- · Check clearance on vehicle.
- Make sure that the billet inserts are secured in place and clears all moving parts of the vehicle.
- Routinely check security of hardware.
- Do not use automatic "brush-style" car washes.

Contents

Illustrations may vary upon application





Tools Required



Safety Glasses and Gloves



Die Grinder




Screwdriver

Flat Head



Rivet Gun



Ratchet with 10mm Socket


Shipping Note

Sometimes the billet products get bent in the shipping process. You may need to hand bend them to attain the desired shape.


Page 1 of 4

Installation Steps

Pop open the hood and remove the plastic rivets from the radiator cover by popping up the center of the rivet with a flat head screwdriver.




Remove the bolts that hold the stock grille shell to the truck. Pull the grille shell upward.





2

Cut away all vertical and horizontal mesh. *Note: Leave the inner black ring!* Next, carefully cut the black mesh from the "tear drop" sides and the molding connected to the inner black ring.




Measure 7/16" inward from the edge of the black ring next to the chrome/paint. Use a die grinder to notch out the sides of the inner ring from where the top begins to curve, down the side, and to the bottom where the inner ring flattens out.





4

Insert the billet grille from the back of the grille shell. Drill and rivet into place.



5

Replace grille shell back into the truck. Reinstall radiator cover and plastic rivets that were removed in Step 1. Make sure everything is secure and close the hood.



6

Page 3 of 4