



**70-1787**

**INSTALLATION INSTRUCTIONS**

1996-Up

Audi / Volkswagen

Bose Integration Harness

**For models amplified without Bose:**

**1996-03 Audi A4 / 1996-03 Audi A6**

**2000-01 Audi S4 / 2002-03 Audi S6**

Use the White, White/Black, Gray, and Gray/Black speaker wire for the front speaker output and use the Green and Purple RCA's for the rear speaker outputs. Be sure to connect the Blue/White wire to the after-market radio's amp turn-on wire. The White and Gray RCA's will not be used.

1-800-221-0932

[www.metraonline.com](http://www.metraonline.com)

© COPYRIGHT 2004 METRA ELECTRONICS CORPORATION



**70-1787**

**INSTALLATION INSTRUCTIONS**

1996-Up

Audi / Volkswagen

Bose Integration Harness

**For models amplified without Bose:**

**1996-03 Audi A4 / 1996-03 Audi A6**

**2000-01 Audi S4 / 2002-03 Audi S6**

Use the White, White/Black, Gray, and Gray/Black speaker wire for the front speaker output and use the Green and Purple RCA's for the rear speaker outputs. Be sure to connect the Blue/White wire to the after-market radio's amp turn-on wire. The White and Gray RCA's will not be used.

1-800-221-0932

[www.metraonline.com](http://www.metraonline.com)

© COPYRIGHT 2004 METRA ELECTRONICS CORPORATION



**70-1787**

**INSTALLATION INSTRUCTIONS**

1996-Up

Audi / Volkswagen

Bose Integration Harness

**For models amplified without Bose:**

**1996-03 Audi A4 / 1996-03 Audi A6**

**2000-01 Audi S4 / 2002-03 Audi S6**

Use the White, White/Black, Gray, and Gray/Black speaker wire for the front speaker output and use the Green and Purple RCA's for the rear speaker outputs. Be sure to connect the Blue/White wire to the after-market radio's amp turn-on wire. The White and Gray RCA's will not be used.

1-800-221-0932

[www.metraonline.com](http://www.metraonline.com)

© COPYRIGHT 2004 METRA ELECTRONICS CORPORATION



**70-1787**

**INSTALLATION INSTRUCTIONS**

1996-Up

Audi / Volkswagen

Bose Integration Harness

**For models amplified without Bose:**

**1996-03 Audi A4 / 1996-03 Audi A6**

**2000-01 Audi S4 / 2002-03 Audi S6**

Use the White, White/Black, Gray, and Gray/Black speaker wire for the front speaker output and use the Green and Purple RCA's for the rear speaker outputs. Be sure to connect the Blue/White wire to the after-market radio's amp turn-on wire. The White and Gray RCA's will not be used.

1-800-221-0932

[www.metraonline.com](http://www.metraonline.com)

© COPYRIGHT 2004 METRA ELECTRONICS CORPORATION



REV. 101304

**For models amplified with Bose:**

1996-03 Audi A4 / 1996-03 Audi A6  
1997-03 Audi A8 / 2000-01 Audi S4  
2002-03 Audi S6 / 2001-03 Audi S8  
2000-03 Audi TT

Use the White and Gray RCA's for the front speaker output and use the Green and Purple RCA's for the rear speaker outputs. Be sure to connect the Blue/White wire to the aftermarket radio's amp turn-on wire. The White, White/Black, Gray, and Gray/Black speaker wires will not be used.

**For all models with power antennas:**

Plug the Blue wire (supplied) in the position above the Yellow wire. Be sure to connect the Blue wire to the aftermarket radio's antenna turn-on wire.



REV. 101304

**For models amplified with Bose:**

1996-03 Audi A4 / 1996-03 Audi A6  
1997-03 Audi A8 / 2000-01 Audi S4  
2002-03 Audi S6 / 2001-03 Audi S8  
2000-03 Audi TT

Use the White and Gray RCA's for the front speaker output and use the Green and Purple RCA's for the rear speaker outputs. Be sure to connect the Blue/White wire to the aftermarket radio's amp turn-on wire. The White, White/Black, Gray, and Gray/Black speaker wires will not be used.

**For all models with power antennas:**

Plug the Blue wire (supplied) in the position above the Yellow wire. Be sure to connect the Blue wire to the aftermarket radio's antenna turn-on wire.



REV. 101304

**For models amplified with Bose:**

1996-03 Audi A4 / 1996-03 Audi A6  
1997-03 Audi A8 / 2000-01 Audi S4  
2002-03 Audi S6 / 2001-03 Audi S8  
2000-03 Audi TT

Use the White and Gray RCA's for the front speaker output and use the Green and Purple RCA's for the rear speaker outputs. Be sure to connect the Blue/White wire to the aftermarket radio's amp turn-on wire. The White, White/Black, Gray, and Gray/Black speaker wires will not be used.

**For all models with power antennas:**

Plug the Blue wire (supplied) in the position above the Yellow wire. Be sure to connect the Blue wire to the aftermarket radio's antenna turn-on wire.



REV. 101304

**For models amplified with Bose:**

1996-03 Audi A4 / 1996-03 Audi A6  
1997-03 Audi A8 / 2000-01 Audi S4  
2002-03 Audi S6 / 2001-03 Audi S8  
2000-03 Audi TT

Use the White and Gray RCA's for the front speaker output and use the Green and Purple RCA's for the rear speaker outputs. Be sure to connect the Blue/White wire to the aftermarket radio's amp turn-on wire. The White, White/Black, Gray, and Gray/Black speaker wires will not be used.

**For all models with power antennas:**

Plug the Blue wire (supplied) in the position above the Yellow wire. Be sure to connect the Blue wire to the aftermarket radio's antenna turn-on wire.