



# 70-2003 INSTALLATION INSTRUCTIONS

## 1998-Up Wiring Harness

(\*) Separate red wire NOT needed for these vehicles:

BUICK	CENTURY	2004-05	ISUZU	ASCENDER	2003-08		
	LACROSSE	2005-09		I SERIES	2006-08		
	RAINIER	2004-07	KIA	*SORENTO EX	2003-06		
	RENDEZVOUS	2002-07		*LX SPORT (DOUBLE DIN)			
CADILLAC	TERRAZA	2005-08	PONTIAC	AZTEC	2001-05		
	ESCALADE (ALL)	2003-06		GRAND AM	2001-04		
CHEVROLET	AVALANCHE (NON BOSE)	2003-06	OLDSMOBILE	GRANDPRIX	2004-08		
	*BLAZER	2002-05		*MATRIX	2003-04		
	COLORADO	2004-09		MONTANA MINI VAN	2000-06		
	CORVETTE	2005-09		SUNFIRE	2000-05		
	EXPRESS	2003-07		*VIBE	2003-08		
	*EXPRESS VAN	2001-02		ALERO	2001-04		
	MONTE CARLO	2000-05		BRAVADA	2002-04		
	SILVERADO	2003-06		INTRIGUE	2002		
	SILVERADO (classic)	2007		SILHOUETTE	2000-04		
	SSR	2003-06		RELAY	2005-07		
	*S-10 PICKUP	2002-04		SUZUKI	*VITARA	1999-04	
	TAHOE (NON-BOSE)	2003-06					
	TRAILBLAZER (NON-BOSE)	2003-09					
	UPLANDER	2005-08					
	VENTURE VAN	2000-05					
	GEO	*METRO		2000-01			
		*PRISM		2000-03			
GMC	*TRACKER	1998-04					
	CANYON	2004-09					
	ENVOY (NON-BOSE)	2002-09					
	SAVANA VAN	2003-07					
	*SAVANA VAN	2001-02					
	SIERRA	2003-06					
	SIERRA (CLASSIC)	2007					
	SONOMA	2002-04					
HUMMER	YUKON (ALL NON-BOSE)	2003-06					
	H2	2003-07					
	H3	2006-09					
HYUNDAI	*SANTA FE W/ MONSOON	2003-06					

**Due to the fact that a switched 12-volt accessory lead does NOT exist in the factory harness, an accessory source must be located. Do NOT use the 2003's 12-volt accessory wire for these vehicles.**

1. Using the separate red wire provided with the fuse tap, locate an accessory power source in the vehicle's fuse box.
2. Connect this red wire to the aftermarket head unit switched accessory lead.
3. Use Metra's standard wiring instructions for the remainder of the installation.

**(NOTE: To retain the factory door chime and customization features use Metra's 70-2003T and SP-2003.)**

**Not for use with Bose or Monsoon Amplified Systems except Hyundai Santa Fe**