

#### INSTALLATION INSTRUCTIONS FOR PART 99-2010

# APPLICATIONS Cadillac STS 2005-2009

# 99-2010


#### KIT FEATURES

- ISO DIN Head Unit Provision With Pocket
- Double DIN Head Unit Provision
- Stacked ISO DIN Head Unit Provision
- Painted matte black to match OEM finish



#### KIT COMPONENTS

A) Radio Housing ullet B) Radio Housing Trim Plate ullet C) Radio Housing Brackets ullet D) Pocket





1-800-221-0932



www.metraonline.com

© COPYRIGHT 2004-2009 METRA ELECTRONICS CORPORATION



## 99-2010

### **TABLE OF CONTENTS**

<u>Dash Disassembly</u>	
- Cadillac STS 2005-2009	. 1
Kit Preparation	2
<u>Kit Assembly</u>	
- ISO DIN Head Unit Provisions with Pocket	Ĵ
- Double DIN Head Unit Provision/Stacked ISO DIN Head Unit Provision.	4

#### \*Note:

Refer also to the instructions included with the aftermarket radio.



# **KNOWLEDGE IS POWER**

Enhance your installation and fabrication skills by enrolling in the most recognized and respected mobile electronics school in our industry.

Log onto www.installerinstitute.com or call 800-354-6782 for more information and take steps toward a better tomorrow.





# 99-2010 DASH DISASSEMBLY

#### CADILLAC 5T5 2005-2009

- 1 Disconnect the negative battery terminal to prevent an accidental short circuit.
- 2 Unclip and remove the entire panel surrounding the radio including the a/c vents. (Figure A)
- 3 Remove (4) 10mm bolts to extract radio from dash. (Figure B)

Continue to kit assembly.






#### 99-2010 KIT PREPARATION


#### CADILLAC 5T5 2005-2009

1 Cut and remove the shaded areas <u>marked with an "E" only</u> from the radio housing. (Figure A) Right side and top of Radio housing. (Figure B) Left side and top of Radio housing.

NOTE: Do NOT remove the tab marked with both "S" and "E".

Continue to kit assembly.









#### 99-2010 KIT A55EMBLY


#### **ISO DIN HEAD UNIT PROVISIONS WITH POCKET**


\*Note: Refer also to the instructions included with the aftermarket radio.

- 1 Locate the factory wiring harness in the dash. Metra recommends using the proper mating adapter from Metra or AXXESS. Re-connect the negative battery terminal and test the unit for proper operation.
- 2 Flip the radio housing brackets upside down then snap them to the inside edge of the radio housing. (Figure A)
- 3 Slide the pocket into the top of the opening aligning the holes in the radio housing brackets with the bosses on the pocket ands secure with the provided (4) #8 3/8" screws. (Figure B)
- 4 Slide the ISO DIN unit into the opening below the pocket and secure the unit to the kit using the screws supplied with the head unit. (Figure C)
- 5 Snap the radio housing trim plate onto the radio housing. (Figure D)
- 6 Reassemble dash in reverse order of disassembly.













# 99-2010 KIT ASSEMBLY


#### DOUBLE DIN HEAD UNIT PROVISION/ STACKED ISO DIN HEAD UNIT PROVISION

\*Note: Refer also to the instructions included with the aftermarket radio.

- 1 Locate the factory wiring harness in the dash. Metra recommends using the proper mating adapter from Metra or AXXESS. Re-connect the negative battery terminal and test the unit for proper operation.
- 2 Snap the radio housing brackets to the inside edge of the Double DIN trim plate. (Figure A)
- 3 Slide the Double DIN head unit or stacked ISO head units into the bracket/radio housing assembly and secure the Double DIN head unit or stacked ISO head units to the assembly using the screws supplied with the radio. (Figure B)
- 4 Snap the radio housing trim plate onto the radio housing. (Figure C)
- 5 Reassemble dash in reverse order of disassembly.









# 99-2010

#### **NOTES**

#### **99-2010 INSTRUCTIONS**



