

XSVI-2003**INSTALLATION INSTRUCTIONS**

In the GM vehicles listed below there are no 12 volt accessory wires currently in the factory harness making the installer run an accessory wire to the fuse box or underneath the steering column when installing an aftermarket radio. The XSVI-2003 is designed to provide a 12 volt 10 amp switched accessory output along with the rest of the wires needed to install an aftermarket radio. The R.A.P. (Retained Accessory Power) function, where power is supplied to the radio after the ignition is shut off until one of the front doors are opened, is retained by the XSVI-2003. **NOTE: The XSVI-2003 does not retain the factory warning chimes that are provided by the factory radio, Onstar, or the factory amplifier if so equipped.**

Wiring the XSVI-2003:

Wiring up the XSVI-2003 is like wiring up any other wire harness that would attach to the aftermarket radios harness. The Metra/EIA wire code can be found on the back of this package that will aid you in the wiring of your aftermarket radio.

INITIALIZE THE XSVI INTERFACE BEFORE TURNING ON RADIO:

With all connections made and harnesses connected to the vehicle, turn ignition key to the ON position for thirty seconds, then turn key off.

(See Applications on back of page)

REV. 05/24/07 INSTXSVI-2003
1-800-221-0932 www.metraonline.com
METRA ELECTRONICS CORPORATION © COPYRIGHT 2007

XSVI-2003**INSTALLATION INSTRUCTIONS**

In the GM vehicles listed below there are no 12 volt accessory wires currently in the factory harness making the installer run an accessory wire to the fuse box or underneath the steering column when installing an aftermarket radio. The XSVI-2003 is designed to provide a 12 volt 10 amp switched accessory output along with the rest of the wires needed to install an aftermarket radio. The R.A.P. (Retained Accessory Power) function, where power is supplied to the radio after the ignition is shut off until one of the front doors are opened, is retained by the XSVI-2003. **NOTE: The XSVI-2003 does not retain the factory warning chimes that are provided by the factory radio, Onstar, or the factory amplifier if so equipped.**

Wiring the XSVI-2003:

Wiring up the XSVI-2003 is like wiring up any other wire harness that would attach to the aftermarket radios harness. The Metra/EIA wire code can be found on the back of this package that will aid you in the wiring of your aftermarket radio.

INITIALIZE THE XSVI INTERFACE BEFORE TURNING ON RADIO:

With all connections made and harnesses connected to the vehicle, turn ignition key to the ON position for thirty seconds, then turn key off.

(See Applications on back of page)

REV. 05/24/07 INSTXSVI-2003
1-800-221-0932 www.metraonline.com
METRA ELECTRONICS CORPORATION © COPYRIGHT 2007

XSVI-2003**INSTALLATION INSTRUCTIONS**

In the GM vehicles listed below there are no 12 volt accessory wires currently in the factory harness making the installer run an accessory wire to the fuse box or underneath the steering column when installing an aftermarket radio. The XSVI-2003 is designed to provide a 12 volt 10 amp switched accessory output along with the rest of the wires needed to install an aftermarket radio. The R.A.P. (Retained Accessory Power) function, where power is supplied to the radio after the ignition is shut off until one of the front doors are opened, is retained by the XSVI-2003. **NOTE: The XSVI-2003 does not retain the factory warning chimes that are provided by the factory radio, Onstar, or the factory amplifier if so equipped.**

Wiring the XSVI-2003:

Wiring up the XSVI-2003 is like wiring up any other wire harness that would attach to the aftermarket radios harness. The Metra/EIA wire code can be found on the back of this package that will aid you in the wiring of your aftermarket radio.

INITIALIZE THE XSVI INTERFACE BEFORE TURNING ON RADIO:

With all connections made and harnesses connected to the vehicle, turn ignition key to the ON position for thirty seconds, then turn key off.

(See Applications on back of page)

REV. 05/24/07 INSTXSVI-2003
1-800-221-0932 www.metraonline.com
METRA ELECTRONICS CORPORATION © COPYRIGHT 2007

XSVI-2003**INSTALLATION INSTRUCTIONS**

In the GM vehicles listed below there are no 12 volt accessory wires currently in the factory harness making the installer run an accessory wire to the fuse box or underneath the steering column when installing an aftermarket radio. The XSVI-2003 is designed to provide a 12 volt 10 amp switched accessory output along with the rest of the wires needed to install an aftermarket radio. The R.A.P. (Retained Accessory Power) function, where power is supplied to the radio after the ignition is shut off until one of the front doors are opened, is retained by the XSVI-2003. **NOTE: The XSVI-2003 does not retain the factory warning chimes that are provided by the factory radio, Onstar, or the factory amplifier if so equipped.**

Wiring the XSVI-2003:

Wiring up the XSVI-2003 is like wiring up any other wire harness that would attach to the aftermarket radios harness. The Metra/EIA wire code can be found on the back of this package that will aid you in the wiring of your aftermarket radio.

INITIALIZE THE XSVI INTERFACE BEFORE TURNING ON RADIO:

With all connections made and harnesses connected to the vehicle, turn ignition key to the ON position for thirty seconds, then turn key off.

(See Applications on back of page)

REV. 05/24/07 INSTXSVI-2003
1-800-221-0932 www.metraonline.com
METRA ELECTRONICS CORPORATION © COPYRIGHT 2007

XSVI-2003**INSTALLATION INSTRUCTIONS**

In the GM vehicles listed below there are no 12 volt accessory wires currently in the factory harness making the installer run an accessory wire to the fuse box or underneath the steering column when installing an aftermarket radio. The XSVI-2003 is designed to provide a 12 volt 10 amp switched accessory output along with the rest of the wires needed to install an aftermarket radio. The R.A.P. (Retained Accessory Power) function, where power is supplied to the radio after the ignition is shut off until one of the front doors are opened, is retained by the XSVI-2003. **NOTE: The XSVI-2003 does not retain the factory warning chimes that are provided by the factory radio, Onstar, or the factory amplifier if so equipped.**

Wiring the XSVI-2003:

Wiring up the XSVI-2003 is like wiring up any other wire harness that would attach to the aftermarket radios harness. The Metra/EIA wire code can be found on the back of this package that will aid you in the wiring of your aftermarket radio.

INITIALIZE THE XSVI INTERFACE BEFORE TURNING ON RADIO:

With all connections made and harnesses connected to the vehicle, turn ignition key to the ON position for thirty seconds, then turn key off.

(See Applications on back of page)

REV. 05/24/07 INSTXSVI-2003
1-800-221-0932 www.metraonline.com
METRA ELECTRONICS CORPORATION © COPYRIGHT 2007

XSVI-2003**INSTALLATION INSTRUCTIONS**

In the GM vehicles listed below there are no 12 volt accessory wires currently in the factory harness making the installer run an accessory wire to the fuse box or underneath the steering column when installing an aftermarket radio. The XSVI-2003 is designed to provide a 12 volt 10 amp switched accessory output along with the rest of the wires needed to install an aftermarket radio. The R.A.P. (Retained Accessory Power) function, where power is supplied to the radio after the ignition is shut off until one of the front doors are opened, is retained by the XSVI-2003. **NOTE: The XSVI-2003 does not retain the factory warning chimes that are provided by the factory radio, Onstar, or the factory amplifier if so equipped.**

Wiring the XSVI-2003:

Wiring up the XSVI-2003 is like wiring up any other wire harness that would attach to the aftermarket radios harness. The Metra/EIA wire code can be found on the back of this package that will aid you in the wiring of your aftermarket radio.

INITIALIZE THE XSVI INTERFACE BEFORE TURNING ON RADIO:

With all connections made and harnesses connected to the vehicle, turn ignition key to the ON position for thirty seconds, then turn key off.

(See Applications on back of page)

REV. 05/24/07 INSTXSVI-2003
1-800-221-0932 www.metraonline.com
METRA ELECTRONICS CORPORATION © COPYRIGHT 2007

APPLICATIONS

BUICK		GMC	
Century	2004-05	Canyon	2004-07
Lacrosse/Allure	2005-2007	Envoy	2002-07
Rainier	2004-07	Savanna	2003-07
Rendezvous	2002-07	Sierra Classic	2007
Terraza	2007	Sierra/Denali	2003-06
CADILLAC		Yukon/XL/Denali	2003-06
Escalade	2003-06	HUMMER	
Escalade EXT	2003-06	H2	2003-07
CHEVROLET		H3	2006-07
Avalanche	2003-06	ISUZU	
Cavalier	2000-05	Ascender	2003-07
Colorado	2004-07	I-Series Truck	2006-07
Corvette	2005-07	OLDSMOBILE	
Express	2003-07	Alero	2002-04
Impala	2000-05	Bravada	2002-05
Kodiak	2003-06	Intrigue	2002
Malibu	2002-04	Silhouette	2000-04
Monte Carlo	2000-05	PONTIAC	
Silverado	2003-06	Aztec	2001-05
Silverado Classic	2007	Grand Am	2001-05
SSR	2003-06	Grand Prix	2004-07
Suburban	2003-06	Montana	2001-05
Tahoe	2003-06	Montana SV6	2005
Trailblazer	2002-07	Sunfire	2000-05
Uplander	2005-07	SAAB	
Venture	2001-05	9-7X	2005-07
		SATURN	
		Relay	2005-07

APPLICATIONS

BUICK		GMC	
Century	2004-05	Canyon	2004-07
Lacrosse/Allure	2005-2007	Envoy	2002-07
Rainier	2004-07	Savanna	2003-07
Rendezvous	2002-07	Sierra Classic	2007
Terraza	2007	Sierra/Denali	2003-06
CADILLAC		Yukon/XL/Denali	2003-06
Escalade	2003-06	HUMMER	
Escalade EXT	2003-06	H2	2003-07
CHEVROLET		H3	2006-07
Avalanche	2003-06	ISUZU	
Cavalier	2000-05	Ascender	2003-07
Colorado	2004-07	I-Series Truck	2006-07
Corvette	2005-07	OLDSMOBILE	
Express	2003-07	Alero	2002-04
Impala	2000-05	Bravada	2002-05
Kodiak	2003-06	Intrigue	2002
Malibu	2002-04	Silhouette	2000-04
Monte Carlo	2000-05	PONTIAC	
Silverado	2003-06	Aztec	2001-05
Silverado Classic	2007	Grand Am	2001-05
SSR	2003-06	Grand Prix	2004-07
Suburban	2003-06	Montana	2001-05
Tahoe	2003-06	Montana SV6	2005
Trailblazer	2002-07	Sunfire	2000-05
Uplander	2005-07	SAAB	
Venture	2001-05	9-7X	2005-07
		SATURN	
		Relay	2005-07

APPLICATIONS

BUICK		GMC	
Century	2004-05	Canyon	2004-07
Lacrosse/Allure	2005-2007	Envoy	2002-07
Rainier	2004-07	Savanna	2003-07
Rendezvous	2002-07	Sierra Classic	2007
Terraza	2007	Sierra/Denali	2003-06
CADILLAC		Yukon/XL/Denali	2003-06
Escalade	2003-06	HUMMER	
Escalade EXT	2003-06	H2	2003-07
CHEVROLET		H3	2006-07
Avalanche	2003-06	ISUZU	
Cavalier	2000-05	Ascender	2003-07
Colorado	2004-07	I-Series Truck	2006-07
Corvette	2005-07	OLDSMOBILE	
Express	2003-07	Alero	2002-04
Impala	2000-05	Bravada	2002-05
Kodiak	2003-06	Intrigue	2002
Malibu	2002-04	Silhouette	2000-04
Monte Carlo	2000-05	PONTIAC	
Silverado	2003-06	Aztec	2001-05
Silverado Classic	2007	Grand Am	2001-05
SSR	2003-06	Grand Prix	2004-07
Suburban	2003-06	Montana	2001-05
Tahoe	2003-06	Montana SV6	2005
Trailblazer	2002-07	Sunfire	2000-05
Uplander	2005-07	SAAB	
Venture	2001-05	9-7X	2005-07
		SATURN	
		Relay	2005-07

APPLICATIONS

BUICK		GMC	
Century	2004-05	Canyon	2004-07
Lacrosse/Allure	2005-2007	Envoy	2002-07
Rainier	2004-07	Savanna	2003-07
Rendezvous	2002-07	Sierra Classic	2007
Terraza	2007	Sierra/Denali	2003-06
CADILLAC		Yukon/XL/Denali	2003-06
Escalade	2003-06	HUMMER	
Escalade EXT	2003-06	H2	2003-07
CHEVROLET		H3	2006-07
Avalanche	2003-06	ISUZU	
Cavalier	2000-05	Ascender	2003-07
Colorado	2004-07	I-Series Truck	2006-07
Corvette	2005-07	OLDSMOBILE	
Express	2003-07	Alero	2002-04
Impala	2000-05	Bravada	2002-05
Kodiak	2003-06	Intrigue	2002
Malibu	2002-04	Silhouette	2000-04
Monte Carlo	2000-05	PONTIAC	
Silverado	2003-06	Aztec	2001-05
Silverado Classic	2007	Grand Am	2001-05
SSR	2003-06	Grand Prix	2004-07
Suburban	2003-06	Montana	2001-05
Tahoe	2003-06	Montana SV6	2005
Trailblazer	2002-07	Sunfire	2000-05
Uplander	2005-07	SAAB	
Venture	2001-05	9-7X	2005-07
		SATURN	
		Relay	2005-07

APPLICATIONS

BUICK		GMC	
Century	2004-05	Canyon	2004-07
Lacrosse/Allure	2005-2007	Envoy	2002-07
Rainier	2004-07	Savanna	2003-07
Rendezvous	2002-07	Sierra Classic	2007
Terraza	2007	Sierra/Denali	2003-06
CADILLAC		Yukon/XL/Denali	2003-06
Escalade	2003-06	HUMMER	
Escalade EXT	2003-06	H2	2003-07
CHEVROLET		H3	2006-07
Avalanche	2003-06	ISUZU	
Cavalier	2000-05	Ascender	2003-07
Colorado	2004-07	I-Series Truck	2006-07
Corvette	2005-07	OLDSMOBILE	
Express	2003-07	Alero	2002-04
Impala	2000-05	Bravada	2002-05
Kodiak	2003-06	Intrigue	2002
Malibu	2002-04	Silhouette	2000-04
Monte Carlo	2000-05	PONTIAC	
Silverado	2003-06	Aztec	2001-05
Silverado Classic	2007	Grand Am	2001-05
SSR	2003-06	Grand Prix	2004-07
Suburban	2003-06	Montana	2001-05
Tahoe	2003-06	Montana SV6	2005
Trailblazer	2002-07	Sunfire	2000-05
Uplander	2005-07	SAAB	
Venture	2001-05	9-7X	2005-07
		SATURN	
		Relay	2005-07

APPLICATIONS

BUICK		GMC	
Century	2004-05	Canyon	2004-07
Lacrosse/Allure	2005-2007	Envoy	2002-07
Rainier	2004-07	Savanna	2003-07
Rendezvous	2002-07	Sierra Classic	2007
Terraza	2007	Sierra/Denali	2003-06
CADILLAC		Yukon/XL/Denali	2003-06
Escalade	2003-06	HUMMER	
Escalade EXT	2003-06	H2	2003-07
CHEVROLET		H3	2006-07
Avalanche	2003-06	ISUZU	
Cavalier	2000-05	Ascender	2003-07
Colorado	2004-07	I-Series Truck	2006-07
Corvette	2005-07	OLDSMOBILE	
Express	2003-07	Alero	2002-04
Impala	2000-05	Bravada	2002-05
Kodiak	2003-06	Intrigue	2002
Malibu	2002-04	Silhouette	2000-04
Monte Carlo	2000-05	PONTIAC	
Silverado	2003-06	Aztec	2001-05
Silverado Classic	2007	Grand Am	2001-05
SSR	2003-06	Grand Prix	2004-07
Suburban	2003-06	Montana	2001-05
Tahoe	2003-06	Montana SV6	2005
Trailblazer	2002-07	Sunfire	2000-05
Uplander	2005-07	SAAB	
Venture	2001-05	9-7X	2005-07
		SATURN	
		Relay	2005-07