### <u>XSVI-2104</u> INSTALLATION INSTRUCTIONS

In the GM vehicles listed below there are no 12 volt accessory wires currently in the factory harness making the installer run an accessory wire to the fuse box or underneath the steering column when installing an aftermarket radio. The XSVI-2104 is designed to provide a 12 volt 10 amp switched accessory output along with the rest of the wires needed to install an aftermarket radio. The R.A.P. (Retained Accessory Power) function, where power is supplied to the radio after the ignition is shut off until one of the front doors are opened, is retained by the XSVI-2104. **NOTE: The XSVI-2104 does not retain the factory warning chimes, Onstar, or the factory amplifier if so equipped.** 

INITIALIZE THE XSVI INTERFACE BEFORE TURNING ON RADIO: With all connections made and harnesses connected to the vehicle, turn ignition key to the ON position for thirty seconds, then turn key off.

#### Wiring the XSVI-2104:

Wiring up the XSVI-2104 is like wiring up any other wire harness that would attach to the aftermarket radios harness. The Metra/EIA wire code can be found on the back of this package that will aid you in the wiring of your aftermarket radio.

(See Applications on back of page)

## <u>XSVI-2104</u> INSTALLATION INSTRUCTIONS

In the GM vehicles listed below there are no 12 volt accessory wires currently in the factory harness making the installer run an accessory wire to the fuse box or underneath the steering column when installing an aftermarket radio. The XSVI-2104 is designed to provide a 12 volt 10 amp switched accessory output along with the rest of the wires needed to install an aftermarket radio. The R.A.P. (Retained Accessory Power) function, where power is supplied to the radio after the ignition is shut off until one of the front doors are opened, is retained by the XSVI-2104. **NOTE: The XSVI-2104 does not retain the factory warning chimes, Onstar, or the factory amplifier if so equipped.** 

INITIALIZE THE XSVI INTERFACE BEFORE TURNING ON RADIO: With all connections made and harnesses connected to the vehicle, turn ignition key to the ON position for thirty seconds, then turn key off.

#### Wiring the XSVI-2104:

Wiring up the XSVI-2104 is like wiring up any other wire harness that would attach to the aftermarket radios harness. The Metra/EIA wire code can be found on the back of this package that will aid you in the wiring of your aftermarket radio.

(See Applications on back of page)

### <u>X5VI-2104</u> INSTALLATION INSTRUCTIONS

In the GM vehicles listed below there are no 12 volt accessory wires currently in the factory harness making the installer run an accessory wire to the fuse box or underneath the steering column when installing an aftermarket radio. The XSVI-2104 is designed to provide a 12 volt 10 amp switched accessory output along with the rest of the wires needed to install an aftermarket radio. The R.A.P. (Retained Accessory Power) function, where power is supplied to the radio after the ignition is shut off until one of the front doors are opened, is retained by the XSVI-2104. NOTE: The XSVI-2104 does not retain the factory warning chimes, Onstar, or the factory amplifier if so equipped.

INITIALIZE THE XSVI INTERFACE BEFORE TURNING ON RADIO: With all connections made and harnesses connected to the vehicle, turn ignition key to the ON position for thirty seconds, then turn key off.

#### Wiring the XSVI-2104:

Wiring up the XSVI-2104 is like wiring up any other wire harness that would attach to the aftermarket radios harness. The Metra/EIA wire code can be found on the back of this package that will aid you in the wiring of your aftermarket radio.

(See Applications on back of page)

### X5VI-2104 INSTALLATION INSTRUCTIONS

In the GM vehicles listed below there are no 12 volt accessory wires currently in the factory harness making the installer run an accessory wire to the fuse box or underneath the steering column when installing an aftermarket radio. The XSVI-2104 is designed to provide a 12 volt 10 amp switched accessory output along with the rest of the wires needed to install an aftermarket radio. The R.A.P. (Retained Accessory Power) function, where power is supplied to the radio after the ignition is shut off until one of the front doors are opened, is retained by the XSVI-2104. **NOTE: The XSVI-2104 does not retain the factory warning chimes, Onstar, or the factory amplifier if so equipped.** 

INITIALIZE THE XSVI INTERFACE BEFORE TURNING ON RADIO: With all connections made and harnesses connected to the vehicle, turn ignition key to the ON position for thirty seconds, then turn key off.

### Wiring the XSVI-2104:

Wiring up the XSVI-2104 is like wiring up any other wire harness that would attach to the aftermarket radios harness. The Metra/EIA wire code can be found on the back of this package that will aid you in the wiring of your aftermarket radio.

(See Applications on back of page)

### X5VI-2104 INSTALLATION INSTRUCTIONS

In the GM vehicles listed below there are no 12 volt accessory wires currently in the factory harness making the installer run an accessory wire to the fuse box or underneath the steering column when installing an aftermarket radio. The XSVI-2104 is designed to provide a 12 volt 10 amp switched accessory output along with the rest of the wires needed to install an aftermarket radio. The R.A.P. (Retained Accessory Power) function, where power is supplied to the radio after the ignition is shut off until one of the front doors are opened, is retained by the XSVI-2104. <u>NOTE: The XSVI-2104 does not retain the factory</u> warning chimes, Onstar, or the factory amplifier if so equipped.

INITIALIZE THE XSVI INTERFACE BEFORE TURNING <u>ON RADIO</u>: With all connections made and harnesses connected to the vehicle, turn ignition key to the ON position for thirty seconds, then turn key off.

#### Wiring the XSVI-2104:

Wiring up the XSVI-2104 is like wiring up any other wire harness that would attach to the aftermarket radios harness. The Metra/EIA wire code can be found on the back of this package that will aid you in the wiring of your aftermarket radio.

(See Applications on back of page)

### XSVI-2104 INSTALLATION INSTRUCTIONS

In the GM vehicles listed below there are no 12 volt accessory wires currently in the factory harness making the installer run an accessory wire to the fuse box or underneath the steering column when installing an aftermarket radio. The XSVI-2104 is designed to provide a 12 volt 10 amp switched accessory output along with the rest of the wires needed to install an aftermarket radio. The R.A.P. (Retained Accessory Power) function, where power is supplied to the radio after the ignition is shut off until one of the front doors are opened, is retained by the XSVI-2104. **NOTE: The XSVI-2104 does not retain the factory warning chimes, Onstar, or the factory amplifier if so equipped.** 

INITIALIZE THE XSVI INTERFACE BEFORE TURNING <u>ON RADIO</u>: With all connections made and harnesses connected to the vehicle, turn ignition key to the ON position for thirty seconds, then turn key off.

#### Wiring the XSVI-2104:

Wiring up the XSVI-2104 is like wiring up any other wire harness that would attach to the aftermarket radios harness. The Metra/EIA wire code can be found on the back of this package that will aid you in the wiring of your aftermarket radio.

(See Applications on back of page)

## <u>X5VI-2104</u> INSTALLATION INSTRUCTIONS

In the GM vehicles listed below there are no 12 volt accessory wires currently in the factory harness making the installer run an accessory wire to the fuse box or underneath the steering column when installing an aftermarket radio. The XSVI-2104 is designed to provide a 12 volt 10 amp switched accessory output along with the rest of the wires needed to install an aftermarket radio. The R.A.P. (Retained Accessory Power) function, where power is supplied to the radio after the ignition is shut off until one of the front doors are opened, is retained by the XSVI-2104. **NOTE: The XSVI-2104 does not retain the factory warning chimes, Onstar, or the factory amplifier if so equipped.** 

INITIALIZE THE XSVI INTERFACE BEFORE TURNING <u>ON RADIO</u>: With all connections made and harnesses connected to the vehicle, turn ignition key to the ON position for thirty seconds, then turn key off.

#### Wiring the XSVI-2104:

Wiring up the XSVI-2104 is like wiring up any other wire harness that would attach to the aftermarket radios harness. The Metra/EIA wire code can be found on the back of this package that will aid you in the wiring of your aftermarket radio.

(See Applications on back of page)

## X5VI-2104 INSTALLATION INSTRUCTIONS

In the GM vehicles listed below there are no 12 volt accessory wires currently in the factory harness making the installer run an accessory wire to the fuse box or underneath the steering column when installing an aftermarket radio. The XSVI-2104 is designed to provide a 12 volt 10 amp switched accessory output along with the rest of the wires needed to install an aftermarket radio. The R.A.P. (Retained Accessory Power) function, where power is supplied to the radio after the ignition is shut off until one of the front doors are opened, is retained by the XSVI-2104. **NOTE: The XSVI-2104 does not retain the factory warning chimes, Onstar, or the factory amplifier if so equipped.** 

INITIALIZE THE XSVI INTERFACE BEFORE TURNING <u>ON RADIO:</u> With all connections made and harnesses connected to the vehicle, turn ignition key to the ON position for thirty seconds, then turn key off.

#### Wiring the XSVI-2104:

Wiring up the XSVI-2104 is like wiring up any other wire harness that would attach to the aftermarket radios harness. The Metra/EIA wire code can be found on the back of this package that will aid you in the wiring of your aftermarket radio.

(See Applications on back of page)

APPI	ICATIONS	<u>APPL</u>	ICATIONS	APPL	ICATIONS	APPL	ICATIONS
<u>CHEVROLET</u> HHR Cobalt	2006-07 2007	CHEVROLET HHR Cobalt	2006-07 2007	<u>CHEVROLET</u> HHR Cobalt	2006-07 2007	CHEVROLET HHR Cobalt	2006-07 2007
PONTIAC G5 Solstice	2007 2006-07	PONTIAC G5 Solstice	2007 2006-07	PONTIAC G5 Solstice	2007 2006-07	PONTIAC G5 Solstice	2007 2006-07
<mark>SATURN</mark> Aura Sky	2006-07 2006-07	<mark>SATURN</mark> Aura Sky	2006-07 2006-07	<mark>SATURN</mark> Aura Sky	2006-07 2006-07	<mark>SATURN</mark> Aura Sky	2006-07 2006-07
REV. 05/29/07	INSTXSVI-2104	REV. 05/29/07	INSTXSVI-2104	REV. 05/29/07	INSTXSVI-2104	REV. 05/29/07	INSTXSVI-2104
-	www.metraonline.com TRONICS CORPORATION IPYRIGHT 2007		www.metraonline.com RONICS CORPORATION PYRIGHT 2007	-	www.metraonline.com RONICS CORPORATION PYRIGHT 2007		www.metraonline.com RONICS CORPORATION PYRIGHT 2007

<b>APPLICATIONS</b>	
	1

1

CHEVROLET HHR Cobalt	2006-07 2007
PONTIAC G5 Solstice	2007 2006-07
<b>SATURN</b> Aura Sky	2006-07 2006-07
METRA ELECTI	INSTXSVI-2104 www.metraonline.com RONICS CORPORATION YRIGHT 2007

APPL	ICATIONS	
CHEVROLET HHR Cobalt	2006-07 2007	
PONTIAC G5 Solstice	2007 2006-07	
<mark>SATURN</mark> Aura Sky	2006-07 2006-07	
REV. 05/29/07	INSTXSVI-2104	
1-800-221-0932 www.metraonline.com METRA ELECTRONICS CORPORATION © COPYRIGHT 2007		

APP	LICAT	IONS E

<u>CHEVROLET</u> HHR Cobalt	2006-07 2007
PONTIAC G5 Solstice	2007 2006-07
SATURN Aura Sky	2006-07 2006-07
METRA ELECT	INSTXSVI-2104 www.metraonline.com RONICS CORPORATION YRIGHT 2007

# APPLICATIONS

<u>CHEVROLET</u> HHR Cobalt	2006-07 2007
PONTIAC G5 Solstice	2007 2006-07
<mark>SATURN</mark> Aura Sky	2006-07 2006-07
REV. 05/29/07 1-800-221-0932 Metra Electron © Copyri	ICS CORPORATION