X5VI-6502-NAV INSTALLATION INSTRUCTIONS

In the In the Chrysler/Dodge/Jeep vehicles listed on back there are no 12 volt accessory wires in the factory radio harness making the installer run an accessory wire to the fuse box or underneath the steering column when installing an aftermarket radio. The XSVI-6502-NAV is designed to provide a 12 volt 10 amp switched accessory output along with the rest of the wires needed to install an aftermarket radio. The R.A.P. (Retained Accessory Power) function is retained by the XSVI-6502-NAV.

The XSVI-6502-NAV also provides essential wires required for aftermarket radios that have navigation. Provided is VSS (Vehicle Speed Sense), Reverse, and Parking Brake. This cuts down the installation time since the installer does not have to look for these wires in the vehicle.

Note: the XSVI-6502-NAV does not retain OEM amplifiers.

<u>Wiring the XSVI-6502-NAV</u>: Wiring up the XSVI-6502-NAV is like wiring up any other wire harness that would attach to the aftermarket radios harness. The Metra/EIA wire code can be found on the back of this package that will aid you in the wiring of your aftermarket radio.

<u>Navigation wire colors:</u> Blue/Pink – VSS (Vehicle Speed Sense) Green/Violet – Reverse Lt. Green – Parking Brake

INITIALIZE THE XSVI INTERFACE BEFORE TURNING ON RADIO: With all connections made and harnesses connected to the vehicle, turn ignition key to the ON position for thirty seconds, then turn key off.

(See Applications on back of page)

INSTXSVI-6502-NAV REV. 11/06/07 1-800-221-0932 www.metraonline.com METRA ELECTRONICS CORPORATION © COPYRIGHT 2007

X5VI-6502-NAV INSTALLATION INSTRUCTIONS

In the In the Chrysler/Dodge/Jeep vehicles listed on back there are no 12 volt accessory wires in the factory radio harness making the installer run an accessory wire to the fuse box or underneath the steering column when installing an aftermarket radio. The XSVI-6502-NAV is designed to provide a 12 volt 10 amp switched accessory output along with the rest of the wires needed to install an aftermarket radio. The R.A.P. (Retained Accessory Power) function is retained by the XSVI-6502-NAV.

The XSVI-6502-NAV also provides essential wires required for aftermarket radios that have navigation. Provided is VSS (Vehicle Speed Sense), Reverse, and Parking Brake. This cuts down the installation time since the installer does not have to look for these wires in the vehicle.

Note: the XSVI-6502-NAV does not retain OEM amplifiers.

Wiring the XSVI-6502-NAV: Wiring up the XSVI-6502-NAV is like wiring up any other wire harness that would attach to the aftermarket radios harness. The Metra/EIA wire code can be found on the back of this package that will aid you in the wiring of your aftermarket radio.

<u>Navigation wire colors:</u> Blue/Pink – VSS (Vehicle Speed Sense) Green/Violet – Reverse Lt. Green – Parking Brake

INITIALIZE THE XSVI INTERFACE BEFORE TURNING ON RADIO: With all connections made and harnesses connected to the vehicle, turn ignition key to the ON position for thirty seconds, then turn key off.

(See Applications on back of page)

 INSTXSVI-6502-NAV
 REV. 11/06/07

 1-800-221-0932
 www.metraonline.com
 METRA ELECTRONICS CORPORATION
 © COPYRIGHT 2007

X5VI-6502-NAV INSTALLATION INSTRUCTIONS

In the In the Chrysler/Dodge/Jeep vehicles listed on back there are no 12 volt accessory wires in the factory radio harness making the installer run an accessory wire to the fuse box or underneath the steering column when installing an aftermarket radio. The XSVI-6502-NAV is designed to provide a 12 volt 10 amp switched accessory output along with the rest of the wires needed to install an aftermarket radio. The R.A.P. (Retained Accessory Power) function is retained by the XSVI-6502-NAV.

The XSVI-6502-NAV also provides essential wires required for aftermarket radios that have navigation. Provided is VSS (Vehicle Speed Sense), Reverse, and Parking Brake. This cuts down the installation time since the installer does not have to look for these wires in the vehicle.

Note: the XSVI-6502-NAV does not retain OEM amplifiers.

<u>Wiring the XSVI-6502-NAV</u>: Wiring up the XSVI-6502-NAV is like wiring up any other wire harness that would attach to the aftermarket radios harness. The Metra/EIA wire code can be found on the back of this package that will aid you in the wiring of your aftermarket radio.

<u>Navigation wire colors:</u> Blue/Pink – VSS (Vehicle Speed Sense) Green/Violet – Reverse Lt. Green – Parking Brake

INITIALIZE THE XSVI INTERFACE BEFORE TURNING ON RADIO: With all connections made and harnesses connected to the vehicle, turn ignition key to the ON position for thirty seconds, then turn key off.

(See Applications on back of page)

 INSTXSVI-6502-NAV
 REV. 11/06/07

 1-800-221-0932
 www.metraonline.com
 METRA ELECTRONICS CORPORATION
 © COPYRIGHT 2007

X5VI-6502-NAV INSTALLATION INSTRUCTIONS

In the In the Chrysler/Dodge/Jeep vehicles listed on back there are no 12 volt accessory wires in the factory radio harness making the installer run an accessory wire to the fuse box or underneath the steering column when installing an aftermarket radio. The XSVI-6502-NAV is designed to provide a 12 volt 10 amp switched accessory output along with the rest of the wires needed to install an aftermarket radio. The R.A.P. (Retained Accessory Power) function is retained by the XSVI-6502-NAV.

The XSVI-6502-NAV also provides essential wires required for aftermarket radios that have navigation. Provided is VSS (Vehicle Speed Sense), Reverse, and Parking Brake. This cuts down the installation time since the installer does not have to look for these wires in the vehicle.

Note: the XSVI-6502-NAV does not retain OEM amplifiers.

<u>Wiring the XSVI-6502-NAV</u>: Wiring up the XSVI-6502-NAV is like wiring up any other wire harness that would attach to the aftermarket radios harness. The Metra/EIA wire code can be found on the back of this package that will aid you in the wiring of your aftermarket radio.

<u>Navigation wire colors:</u> Blue/Pink – VSS (Vehicle Speed Sense) Green/Violet – Reverse Lt. Green – Parking Brake

INITIALIZE THE XSVI INTERFACE BEFORE TURNING ON RADIO: With all connections made and harnesses connected to the vehicle, turn ignition key to the ON position for thirty seconds, then turn key off.

(See Applications on back of page)

INSTXSVI-6502-NAV REV. 11/06/07 1-800-221-0932 www.metraonline.com METRA ELECTRONICS CORPORATION © COPYRIGHT 2007

X5VI-6502-NAV INSTALLATION INSTRUCTIONS

In the In the Chrysler/Dodge/Jeep vehicles listed on back there are no 12 volt accessory wires in the factory radio harness making the installer run an accessory wire to the fuse box or underneath the steering column when installing an aftermarket radio. The XSVI-6502-NAV is designed to provide a 12 volt 10 amp switched accessory output along with the rest of the wires needed to install an aftermarket radio. The R.A.P. (Retained Accessory Power) function is retained by the XSVI-6502-NAV.

The XSVI-6502-NAV also provides essential wires required for aftermarket radios that have navigation. Provided is VSS (Vehicle Speed Sense), Reverse, and Parking Brake. This cuts down the installation time since the installer does not have to look for these wires in the vehicle.

Note: the XSVI-6502-NAV does not retain OEM amplifiers.

<u>Wiring the XSVI-6502-NAV</u>: Wiring up the XSVI-6502-NAV is like wiring up any other wire harness that would attach to the aftermarket radios harness. The Metra/EIA wire code can be found on the back of this package that will aid you in the wiring of your aftermarket radio.

<u>Navigation wire colors:</u> Blue/Pink – VSS (Vehicle Speed Sense) Green/Violet – Reverse Lt. Green – Parking Brake

INITIALIZE THE XSVI INTERFACE BEFORE TURNING ON RADIO: With all connections made and harnesses connected to the vehicle, turn ignition key to the ON position for thirty seconds, then turn key off.

(See Applications on back of page)			
INSTXSVI-6502-NAV		REV. 11/06/07	
1-800-221-0932	www.metraonline.com	METRA ELECTRONICS CORPORATION	© COPYRIGHT 2007

X5VI-6502-NAV INSTALLATION INSTRUCTIONS

In the In the Chrysler/Dodge/Jeep vehicles listed on back there are no 12 volt accessory wires in the factory radio harness making the installer run an accessory wire to the fuse box or underneath the steering column when installing an aftermarket radio. The XSVI-6502-NAV is designed to provide a 12 volt 10 amp switched accessory output along with the rest of the wires needed to install an aftermarket radio. The RA.P. (Retained Accessory Power) function is retained by the XSVI-6502-NAV.

The XSVI-6502-NAV also provides essential wires required for aftermarket radios that have navigation. Provided is VSS (Vehicle Speed Sense), Reverse, and Parking Brake. This cuts down the installation time since the installer does not have to look for these wires in the vehicle.

Note: the XSVI-6502-NAV does not retain OEM amplifiers.

<u>Wiring the XSVI-6502-NAV</u>: Wiring up the XSVI-6502-NAV is like wiring up any other wire harness that would attach to the aftermarket radios harness. The Metra/EIA wire code can be found on the back of this package that will aid you in the wiring of your aftermarket radio.

Navigation wire colors: Blue/Pink – VSS (Vehicle Speed Sense) Green/Violet – Reverse Lt. Green – Parking Brake

INITIALIZE THE XSVI INTERFACE BEFORE TURNING ON RADIO: With all connections made and harnesses connected to the vehicle, turn ignition key to the ON position for thirty seconds, then turn key off.

(See Applications on back of page)

 INSTXSVI-6502-NAV
 REV. 11/06/07

 1-800-221-0932
 www.metraonline.com
 METRA ELECTRONICS CORPORATION
 © COPYRIGHT 2007

APPLICATIONS

CHRYSLER

300	2005-07
Aspen	2007
Pacifica	2003-07
PT Cruiser	2006-07

DODGE

DODOL	
Caliber	2007
Charger	2005-07
Dakota	2005-07
Durango	2005-07
Magnum	2005-07
Ram	2006-07

JEEP Grand Cherokee 20 Commander 20 Compass 20 Patriot 20

MITSUBISHI Raider

APPLICATIONS

2005-07

2005-07 2007 2003-07 2006-07

2005-07

CHRYSLER

UNICIOLEN	
300	
Aspen	
Pacifica	
PT Cruiser	

DODGE

DODOL	
Caliber	2007
Charger	2005-07
Dakota	2005-07
Durango	2005-07
Magnum	2005-07
Ram	2006-07

JEEP Grand Charakaa

Grand Cherokee	2005-07
Commander	2006-07
Compass	2007
Patriot	2007

<u>MITSUBISHI</u> Raider

APPLICATIONS

CHRYSLER 300 Aspen Pacifica PT Cruiser	2005-07 2007 2003-07 2006-07
DODGE Caliber Charger Dakota Durango Magnum Ram	2007 2005-07 2005-07 2005-07 2005-07 2006-07
JEEP Grand Cherokee Commander Compass Patriot	2005-07 2006-07 2007 2007

MITSUBISHI Raider

2005-07

APPLICATIONS

300 Aspen Pacifica PT Crui		2005-07 2007 2003-07 2006-07
DODGE Caliber Charger Dakota Durango Magnun Ram	- D	2007 2005-07 2005-07 2005-07 2005-07 2006-07
JEEP Grand C Comma Compas Patriot		2005-07 2006-07 2007 2007
<u>MITSUE</u> Raider	<u>BISHI</u>	2005-07

APPLICATIONS

<u>CHRYSLER</u> 300 Aspen Pacifica PT Cruiser	2005-07 2007 2003-07 2006-07
DODGE Caliber Charger Dakota Durango Magnum Ram	2007 2005-07 2005-07 2005-07 2005-07 2006-07
JEEP Grand Cherokee Commander Compass Patriot	2005-07 2006-07 2007 2007
<u>MITSUBISHI</u> Raider	2005-07

APPLICATIONS

CHRYSLER 300 Aspen Pacifica PT Cruiser	2005-07 2007 2003-07 2006-07
DODGE Caliber Charger Dakota Durango Magnum Ram	2007 2005-07 2005-07 2005-07 2005-07 2006-07
JEEP Grand Cherokee Commander Compass Patriot	2005-07 2006-07 2007 2007
<u>MITSUBISHI</u> Raider	2005-07