#### X5VI-6522-NAV INSTALLATION INSTRUCTIONS

In the Chrysler/Dodge/Jeep vehicles listed on back there are no 12 volt accessory wires in the factory radio harness making the installer run an accessory wire to the fuse box or underneath the steering column when installing an aftermarket radio. The XSVI-6522-NAV is designed to provide a 12 volt 10 amp switched accessory output along with the rest of the wires needed to install an aftermarket radio. The R.A.P. (Retained Accessory Power) function is retained by the XSVI-6522-NAV.

The XSVI-6522-NAV also provides essential wires required for aftermarket radios that have navigation. Provided is VSS (Vehicle Speed Sense), Reverse, and Parking Brake. This cuts down the installation time since the installer does not have to look for these wires in the vehicle.

Note: the XSVI-6522-NAV does not retain OEM amplifiers.

Wiring the XSVI-6522-NAV: Wiring up the XSVI-6522-NAV is like wiring up any other wire harness that would attach to the aftermarket radios harness. The Metra/EIA wire code can be found on the back of this package that will aid you in the wiring of your aftermarket radio.

> Navigation wire colors: Blue/Pink - VSS (Vehicle Speed Sense) Green/Violet - Reverse Lt. Green - Parking Brake

INITIALIZE THE XSVI INTERFACE BEFORE TURNING ON RADIO: With all connections made and harnesses connected to the vehicle, turn ignition key to the ON position for thirty seconds, then turn key off.

(See Applications on back of page)

INSTXSVI-6522-NAV

REV. 04/10/08

1-800-221-0932 www.metraonline.com Metra electronics corporation © copyright 2007-08

### X5VI-6522-NAV INSTALLATION INSTRUCTIONS

In the Chrysler/Dodge/Jeep vehicles listed on back there are no 12 volt accessory wires in the factory radio harness making the installer run an accessory wire to the fuse box or underneath the steering column when installing an aftermarket radio. The XSVI-6522-NAV is designed to provide a 12 volt 10 amp switched accessory output along with the rest of the wires needed to install an aftermarket radio. The R.A.P. (Retained Accessory Power) function is retained by the XSVI-6522-NAV.

The XSVI-6522-NAV also provides essential wires required for aftermarket radios that have navigation. Provided is VSS (Vehicle Speed Sense), Reverse, and Parking Brake. This cuts down the installation time since the installer does not have to look for these wires in the vehicle.

Note: the XSVI-6522-NAV does not retain OEM amplifiers.

Wiring the XSVI-6522-NAV: Wiring up the XSVI-6522-NAV is like wiring up any other wire harness that would attach to the aftermarket radios harness. The Metra/EIA wire code can be found on the back of this package that will aid you in the wiring of your aftermarket radio.

Navigation wire colors: Blue/Pink - VSS (Vehicle Speed Sense) Green/Violet - Reverse Lt. Green - Parking Brake

INITIALIZE THE XSVI INTERFACE BEFORE TURNING ON RADIO: With all connections made and harnesses connected to the vehicle, turn ignition key to the ON position for thirty seconds, then turn key off.

(See Applications on back of page)

INSTXSVI-6522-NAV

REV. 04/10/08

1-800-221-0932 www.metraonline.com Metra Electronics Corporation © Copyright 2007-08

# X5VI-6522-NAV INSTALLATION INSTRUCTIONS

In the Chrysler/Dodge/Jeep vehicles listed on back there are no 12 volt accessory wires in the factory radio harness making the installer run an accessory wire to the fuse box or underneath the steering column when installing an aftermarket radio. The XSVI-6522-NAV is designed to provide a 12 volt 10 amp switched accessory output along with the rest of the wires needed to install an aftermarket radio. The R.A.P. (Retained Accessory Power) function is retained by the XSVI-6522-NAV.

The XSVI-6522-NAV also provides essential wires required for aftermarket radios that have navigation. Provided is VSS (Vehicle Speed Sense), Reverse, and Parking Brake. This cuts down the installation time since the installer does not have to look for these wires in the vehicle.

Note: the XSVI-6522-NAV does not retain OEM amplifiers.

Wiring the XSVI-6522-NAV: Wiring up the XSVI-6522-NAV is like wiring up any other wire harness that would attach to the aftermarket radios harness. The Metra/EIA wire code can be found on the back of this package that will aid you in the wiring of your aftermarket radio.

> Navigation wire colors: Blue/Pink - VSS (Vehicle Speed Sense) Green/Violet - Reverse Lt. Green - Parking Brake

INITIALIZE THE XSVI INTERFACE BEFORE TURNING ON RADIO: With all connections made and harnesses connected to the vehicle, turn ignition key to the ON position for thirty seconds, then turn key off.

(See Applications on back of page)

INSTXSVI-6522-NAV REV. 04/10/08 1-800-221-0932 www.metraonline.com METRA FLECTRONICS CORPORATION © COPYRIGHT 2007-08

#### X5VI-6522-NAV INSTALLATION INSTRUCTIONS

In the Chrysler/Dodge/Jeep vehicles listed on back there are no 12 volt accessory wires in the factory radio harness making the installer run an accessory wire to the fuse box or underneath the steering column when installing an aftermarket radio. The XSVI-6522-NAV is designed to provide a 12 volt 10 amp switched accessory output along with the rest of the wires needed to install an aftermarket radio. The R.A.P. (Retained Accessory Power) function is retained by the XSVI-6522-NAV.

The XSVI-6522-NAV also provides essential wires required for aftermarket radios that have navigation. Provided is VSS (Vehicle Speed Sense), Reverse, and Parking Brake. This cuts down the installation time since the installer does not have to look for these wires in the vehicle.

Note: the XSVI-6522-NAV does not retain OEM amplifiers.

Wiring the XSVI-6522-NAV: Wiring up the XSVI-6522-NAV is like wiring up any other wire harness that would attach to the aftermarket radios harness. The Metra/EIA wire code can be found on the back of this package that will aid you in the wiring of your aftermarket radio.

> Navigation wire colors: Blue/Pink - VSS (Vehicle Speed Sense) Green/Violet - Reverse Lt. Green - Parking Brake

INITIALIZE THE XSVI INTERFACE BEFORE TURNING ON RADIO: With all connections made and harnesses connected to the vehicle, turn ignition key to the ON position for thirty seconds, then turn kev off.

(See Applications on back of page)

REV. 04/10/08

1-800-221-0932 www.metraonline.com Metra Flectronics Corporation © Copyright 2007-08

### X5VI-6522-NAV INSTALLATION INSTRUCTIONS

In the Chrysler/Dodge/Jeep vehicles listed on back there are no 12 volt accessory wires in the factory radio harness making the installer run an accessory wire to the fuse box or underneath the steering column when installing an aftermarket radio. The XSVI-6522-NAV is designed to provide a 12 volt 10 amp switched accessory output along with the rest of the wires needed to install an aftermarket radio. The R.A.P. (Retained Accessory Power) function is retained by the XSVI-6522-NAV.

The XSVI-6522-NAV also provides essential wires required for aftermarket radios that have navigation. Provided is VSS (Vehicle Speed Sense), Reverse, and Parking Brake. This cuts down the installation time since the installer does not have to look for these wires in the vehicle.

Note: the XSVI-6522-NAV does not retain OEM amplifiers.

Wiring the XSVI-6522-NAV: Wiring up the XSVI-6522-NAV is like wiring up any other wire harness that would attach to the aftermarket radios harness. The Metra/EIA wire code can be found on the back of this package that will aid you in the wiring of your aftermarket radio.

**Navigation wire colors:** Blue/Pink - VSS (Vehicle Speed Sense) Green/Violet - Reverse Lt. Green - Parking Brake

INITIALIZE THE XSVI INTERFACE BEFORE TURNING ON RADIO: With all connections made and harnesses connected to the vehicle, turn ignition key to the ON position for thirty seconds, then turn key off.

(See Applications on back of page)

INSTXSVI-6522-NAV

INSTXSVI-6522-NAV

REV. 04/10/08

1-800-221-0932 www.metraonline.com Metra Electronics Corporation © Copyright 2007-08

#### X5VI-6522-NAV INSTALLATION INSTRUCTIONS

In the Chrysler/Dodge/Jeep vehicles listed on back there are no 12 volt accessory wires in the factory radio harness making the installer run an accessory wire to the fuse box or underneath the steering column when installing an aftermarket radio. The XSVI-6522-NAV is designed to provide a 12 volt 10 amp switched accessory output along with the rest of the wires needed to install an aftermarket radio. The R.A.P. (Retained Accessory Power) function is retained by the XSVI-6522-NAV.

The XSVI-6522-NAV also provides essential wires required for aftermarket radios that have navigation. Provided is VSS (Vehicle Speed Sense), Reverse, and Parking Brake. This cuts down the installation time since the installer does not have to look for these wires in the vehicle

Note: the XSVI-6522-NAV does not retain OEM amplifiers.

Wiring the XSVI-6522-NAV: Wiring up the XSVI-6522-NAV is like wiring up any other wire harness that would attach to the aftermarket radios harness. The Metra/EIA wire code can be found on the back of this package that will aid you in the wiring of your aftermarket radio.

**Navigation wire colors:** Blue/Pink - VSS (Vehicle Speed Sense) Green/Violet - Reverse Lt. Green - Parking Brake

INITIALIZE THE XSVI INTERFACE BEFORE TURNING ON RADIO: With all connections made and harnesses connected to the vehicle, turn ignition key to the ON position for thirty seconds, then turn key off.

(See Applications on back of page)

INSTXSVI-6522-NAV

RFV 04/10/08 1-800-221-0932 www.metraonline.com Metra Electronics Corporation © Copyright 2007-08

### **APPLICATIONS**

CHRYSLER
Town & Country 2008
Sebring 2007

**DODGE** 

 Dakota
 2008

 Grand Caravan
 2008

 Journey
 2009

 Nitro
 2007

 Avenger
 2008

<u>JEEP</u>

Wrangler 2007

### APPLICATIONS I

CHRYSLER

Town & Country 2008 Sebring 2007

**DODGE** 

 Dakota
 2008

 Grand Caravan
 2008

 Journey
 2009

 Nitro
 2007

 Avenger
 2008

<u>JEEP</u>

Wrangler 2007

# **APPLICATIONS**

<u>CHRYSLER</u>

Town & Country 2008 Sebring 2007

**DODGE** 

 Dakota
 2008

 Grand Caravan
 2008

 Journey
 2009

 Nitro
 2007

 Avenger
 2008

<u>JEEP</u>

Wrangler 2007

### APPLICATIONS I

CHRYSLER

Town & Country 2008 Sebring 2007

**DODGE** 

 Dakota
 2008

 Grand Caravan
 2008

 Journey
 2009

 Nitro
 2007

 Avenger
 2008

**JEEP** 

Wrangler 2007

## **APPLICATIONS**

CHRYSLER

Town & Country 2008 Sebring 2007

**DODGE** 

 Dakota
 2008

 Grand Caravan
 2008

 Journey
 2009

 Nitro
 2007

 Avenger
 2008

<u>JEEP</u>

Wrangler 2007

## **APPLICATIONS** I

CHRYSLER

Town & Country 2008 Sebring 2007

**DODGE** 

 Dakota
 2008

 Grand Caravan
 2008

 Journey
 2009

 Nitro
 2007

 Avenger
 2008

<u>JEEP</u>

Wrangler 2007