



INSTALLATION INSTRUCTIONS

CHROME PLATED VALVE COVERS – Mr. Gasket Part No. 9415

READ ALL INSTRUCTIONS CAREFULLY BEFORE BEGINNING INSTALLATION. MAKE SURE ENGINE, RADIATOR AND ALL COMPONENTS ARE COOL BEFORE STARTING. NOTE: ON SOME APPLICATIONS, IT MAY BE NECESSARY TO REMOVE OR DISCONNECT VARIOUS AUXILIARY ENGINE COMPONENTS TO PROVIDE CLEARANCE FOR VALVE COVER INSTALLATION.

GENERAL INFORMATION

Mr. Gasket Chrome Plated Valve Covers are a direct replacement for factory inner rail design valve covers on 1987 & up Chevrolet Small Block engines. Grommets and oil filler cap are included.

INSTALLATION PROCEDURE

Step 1

Remove PCV valve(s), sir cleaner breather tube and hold-down bolts from center of valve covers. **NOTE: It is recommended to replace existing valve cover gas-kets to ensure a positive seal. Use Mr. Gasket Part No. 168 or 5867.**

Step 2

Install provided grommets into valve covers and place into cylinder heads. Two hole design fits driver's side and one hole design fits passenger side.

Step 3

Insert hold-down bolts into mounting holes, starting with the two center bolts. Tighten to manufacturer's specifications. **NOTE: Use Mr. Gasket Part No. 9822 to replace existing factory mounting hardware.**

Step 4

Re-install PCV valve(s), air cleaner breather tube and oil fill cap.

Step 5

Replace any auxiliary engine components that may have been removed.

QUESTIONS

Please call our Tech Support line at 1-216-688-8300, M – F, 9 – 5 EST. Please have the part number on hand when you call.



MR. GASKET IS A TRADEMARK OF PRESTOLITE PERFORMANCE
10601 Memphis Ave. #12, Cleveland, OH 44144
216.688.8300 FAX 216.688.8306

FORM 94152012
06/12
Printed in U.S.A.

FORM 94152012



INSTALLATION INSTRUCTIONS

CHROME PLATED VALVE COVERS – Mr. Gasket Part No. 9415

READ ALL INSTRUCTIONS CAREFULLY BEFORE BEGINNING INSTALLATION. MAKE SURE ENGINE, RADIATOR AND ALL COMPONENTS ARE COOL BEFORE STARTING. NOTE: ON SOME APPLICATIONS, IT MAY BE NECESSARY TO REMOVE OR DISCONNECT VARIOUS AUXILIARY ENGINE COMPONENTS TO PROVIDE CLEARANCE FOR VALVE COVER INSTALLATION.

GENERAL INFORMATION

Mr. Gasket Chrome Plated Valve Covers are a direct replacement for factory inner rail design valve covers on 1987 & up Chevrolet Small Block engines. Grommets and oil filler cap are included.

INSTALLATION PROCEDURE

Step 1

Remove PCV valve(s), sir cleaner breather tube and hold-down bolts from center of valve covers. **NOTE: It is recommended to replace existing valve cover gas-kets to ensure a positive seal. Use Mr. Gasket Part No. 168 or 5867.**

Step 2

Install provided grommets into valve covers and place into cylinder heads. Two hole design fits driver's side and one hole design fits passenger side.

Step 3

Insert hold-down bolts into mounting holes, starting with the two center bolts. Tighten to manufacturer's specifications. **NOTE: Use Mr. Gasket Part No. 9822 to replace existing factory mounting hardware.**

Step 4

Re-install PCV valve(s), air cleaner breather tube and oil fill cap.

Step 5

Replace any auxiliary engine components that may have been removed.

QUESTIONS

Please call our Tech Support line at 1-216-688-8300, M – F, 9 – 5 EST. Please have the part number on hand when you call.



MR. GASKET IS A TRADEMARK OF PRESTOLITE PERFORMANCE
10601 Memphis Ave. #12, Cleveland, OH 44144
216.688.8300 FAX 216.688.8306

FORM 94152012
06/12
Printed in U.S.A.