

PUTCO BODY SIDE MOLDING INSTALLATION SHEET

Congratulations on your purchase of a high quality PUTCO product. Should you need any application or technical assistance feel free to call us at:

1-800-247-3974

Monday-Friday 8:00 a.m.- 5:00 p.m. (Central Standard Time)

Contact your PUTCO dealer for other quality accessories.

PUTCO Inc. - 216 West First Street - Story City, Iowa 50248

PLEASE READ ALL INSTRUCTIONS BEFORE INSTALLATION AND TO CHECK TO SEE THAT ALL PARTS ARE INCLUDED.

Putco is not liable for any vehicle damage resulting from the installation of our body side molding.

IMPORTANT: Make sure you have all of the correct pieces before installing.

Step 1: Match the parts up with the doors by length prior to installation.

Step 2: If your vehicle has factory side molding you will need to remove it.

Step 3: Make sure the surface that you are going to apply the side molding to is clean.

Step 4: Install side molding.

Note: PUTCO recommends applying a high quality automotive wax to maintain the original appearance.

LIMITED WARRANTY

Putco guarantees it's Stainless Steel and Aluminum products against defects in workmanship and material for as long as you own your vehicle. All painted products have a 90 day warranty on the painted surface. Any defects resulting from faulty material or workmanship will be warranted by Putco and repaired or replaced at our discretion. Putco assumes no extra labor costs. Damages caused by freight carriers, improper installation, misuse, collision, or neglect will not be warranted by Putco.