

APPLY PRESSURE SENSITIVE TAPES TO A CLEAN, DRY SURFACE THAT ARE IDEALLY AT 50 °F, (10 °C) OR HIGHER. APPLY FIRM AND EVEN PRESSURE TO ENSURE GOOD ADHESION. WHEN USING NAILS OR SCREWS TO MOUNT PLASTIC REFLECTORS, DO NOT OVER TIGHTEN TO AVOID CRACKING THE MATERIAL.