

INSTRUCTION SHEET

JEEP XSTORQUE STARTERS

ELECTRICAL WIRING INSTRUCTIONS

1. Install a jumper wire from the "Bat" terminal connection on the starter solenoid to the "IGN" terminal.

[OPTIONAL: Run the "switch" wire from the starter relay to the "IGN" terminal on the starter solenoid.]



2. Connect the positive battery wire to the "BAT" terminal on the starter solenoid.



1833 Downs Drive, West Chicago IL 60185
Tech : (630) 849-7754 Sales : (630) 957-4019
Tech Email: tech@powermasterperformance.com

INSTRUCTION SHEET

JEEP XSTORQUE STARTERS

ELECTRICAL WIRING INSTRUCTIONS

1. Install a jumper wire from the "Bat" terminal connection on the starter solenoid to the "IGN" terminal.

[OPTIONAL: Run the "switch" wire from the starter relay to the "IGN" terminal on the starter solenoid.]



2. Connect the positive battery wire to the "BAT" terminal on the starter solenoid.



1833 Downs Drive, West Chicago IL 60185
Tech : (630) 849-7754 Sales : (630) 957-4019
Tech Email: tech@powermasterperformance.com