



Standard high back seat (13401.XX)
Standard low back seat (13400.XX)
1976 - 2002 CJ - Wrangler
Installation Instructions

13400.XX
Low Back



13401.XX
High Back



Included components:

- (1) Lower seat section
- (1) Upper seat section
- (4) Hex Head Bolts
- (4) Lock Washers

Seat Assembly:

Step (1) Insert upper seat section to lower seat section through slots located on the back side of lower section.

Step (2) Fold upper section back into upright position.
Turn seat over and pull plastic retainer channel away.

Step (3) Install all 4 bolts and washers(DO NOT TIGHTEN)
After all bolts have been installed tighten and reinstall plastic retainer channel as shown above.

Seat installation instructions:

Step (4) Remove old seat from riser by removing 4 bolts. Save these bolts as they will be reused later.

Step (5) Remove sliders from old seats by removing 4 bolts. Save these bolts as they will be reused later.

NOTE: To access the rear 2 bolts push slider arm down and move slider forward.

Step (6) Place sliders onto new seats. Reuse spacers from the old seat to align the slider.

Step (7) Fasten slider to the new seat using the 4 bolts saved from step 5

Step (8) Carefully place slider back onto seat riser and fasten with 4 bolts saved from step 4

