



Installation Instructions: Standard tilt forward rear seat (1955-1995) CJ – YJ
13461.XX

(Step 1 – Fig. A) Front Seat Brackets.

Remove seat mounting bolts from floor. Locate mounting tabs on the bottom of the seat and cut a slit 2" long to expose tabs. They are located about 4" from each side of the seat bottom. Put hinge bolts through front mounting bracket and tab as seen in (Fig.A). Install washer and hex nut on threaded bolt. **DO NOT OVER TIGHTEN.** Align mounting tab over front mounting holes and securely tighten with seat mounting bolt .

(Step2 – Fig.B) Rear Seat Lock

Remove seat belt anchor bolt from floor. Position lock underneath seat belt & eyelets as shown in (Fig.B). Please note that more than one hole is supplied to align the bracket with the floor mounting hole and seat lock. If desired an additional hole can be drilled and the bracket secured with two bolts. Grade 5 or higher bolt and large washer is recommended (supplied by customer). Reinstall seat belt anchor bolt through seat belt eyelets and seat lock. **DO NOT TIGHTEN YET.**

Align seat lock with striker so that seat locks when the seat is pushed down into position. Tighten seat belt anchor bolt. At this time a second hole, if desired, can be drilled and additional hardware added (supplied by customer).

