

## Jeep® Carpet Kit - Installation Instructions (1976-2006) CJ7 - Wrangler

**Contents:** (1) Front floor cover  
(1) Center floor cover (behind front seats)  
(1) Rear floor cover  
(2) Fender well covers (LH,RH)

**Tools needed:**(1) Box knife  
(1) Marker  
(1) Spray Adhesive



**NOTICE:** For best results a quality spray adhesive must be used to install this carpet kit. This adhesive may be found at most large hardware stores or fabric suppliers.

**WARNING: DO NOT AIR SHIP CARPET KIT.** Some kits may include adhesive that can not be shipped via air freight.

**Step 1:** Remove front and rear seats to ease installation. Clean all mounting surfaces. Make sure work area is dry before carpet is installed. If needed remove shift boot covers.

**Step 2:** Test fit carpet into place as seen in image #1. Make sure that all carpet pieces are supplied in kit.

**NOTICE:** Carpet is supplied with no precut holes or notches. Because of the different variations over the years this task must be performed at the time the carpet is installed.

**WARNING:** Before applying spray adhesive make sure that work area is properly ventilated.

**Step 3:** Remove carpet and proceed with the installation of the LH and RH fender well covers. Mark location of side roll bar and cut only the amount of carpet needed to allow for a flush fit. Spray back of carpet with adhesive and slide into place. Repeat for other side.

**Step 4:** Install rear lower carpet set. Mark hole locations for seat and seatbelt mounting points. Only cut what is needed to expose mounting holes. Apply adhesive and slide into Place.

**Step 5:** Install center carpet section. Mark seat and seatbelt holes if needed and only cut what is needed to expose mounting holes. Apply adhesive and slide into place.

**Step 6:** Install front carpet section and mark holes as needed for seats and shifter knobs. Mark holes as shown and only cut what is needed to expose mounting holes and shift pattern. If needed cut slits at front LH and RH side tub support brackets. Make sure carpet does not interfere with pedal operation and cut to clear if needed. Apply adhesive and slide into place. reinstall seats and shift boots.

