



Installation Instructions

High Endurance Stainless Tube Steps with Step Pads

**Part No. 556 and 5566
2007 Toyota FJ Crusier.**

Parts List:

**2-Front Mount Brackets
8- 8mm Flat Washer
8- 10mm Flat Washer**

**2-Rear Mount Brackets
8- 8mm Locking split washer
8- 10mm Locking split washer**

**8- 8mm x 26mm Hex Head Bolt
8- 10mm x 28mm Hex Head Bolt**

Installation:

- 1 Remove contents from box and identify driver and passenger side bars (Bar will have logo facing out) and brackets for each side of the vehicle. Front brackets have an obtuse angle and two holes on each mounting surface. Rear brackets have one mounting surface with two holes adjacent to each other.

Front
Drivers
Side



- 2 Locate factory pre threaded holes under pinch weld of vehicle; the vehicle will have factory bolts installed. We have included an extra set in the hardware kit. Line up front bracket to factory holes and mount using 8mm factory bolts with flat washers and lock washers. Repeat for all mounting bracket locations. NOTE: Be sure to hand tighten only at this point to ensure proper alignment later.
- 3 Bolt Rampage High Endurance step bars to brackets using remaining 10mm x 1.25" bolts, flat washers and lock washers. Hand-tighten only at this point.
- 4 After insuring that all parts are properly aligned and step tube surface is level, tighten all bolts. Repeat steps 1 through 5 for opposite side of vehicle to complete installation of Rampage High Endurance Tube Steps.

**Rampage Products 9225 Stellar Ct. Ste C. Corona Ca., 92883
Phone: (951) 277-4949 Fax: (951) 277-2295
Web: www.rampageproducts.net**

Made in China