



Installation Instructions

Billet Gas Door

Part No. 75013, 87013 - 03 and Up Hummer H2

Parts List:

- 1- Gas Door**
- 2- Keys**
- 12-Machine Screws (Pre-Assembled)**

Tools Needed

- Ratchet**
- 7mm open end wrench**
- Philips screwdriver**

Installation:

- 1) Remove original gas cap.
- 2) Remove the three 7mm bolts around the filler neck
- 3) To remove the plastic shroud; turn counter clockwise and pull out.
- 4) Lay the gas door face down and remove all 12 small machine screws around the edge.
- 5) Place the factory plastic shroud on top of the gas door; align the drain hole on the plastic shroud between the two closest holes on the bottom of the gas door (next to part number).
- 6) Install the twelve small machine screws around the edge of the gas door, make sure the plastic shroud is seated correctly. After both parts are assembled the lock should be on the right hand side when looking at the front of the gas door.
- 7) Reinstall plastic shroud onto the vehicle be tuning clockwise, reinstall three 7mm bolts around the filler neck.

Rampage Products 9225 Stellar Ct, Corona, CA 92883
Phone: (951) 24277-4949 Fax: (951) 277-2295
Web: www.rampageproducts.net

Made in China