

ITEM#	DESCRIPTION	QTY
7000WS	WHITE STEERING DAMPER	2
7213-MB	03DODGE,MAIN BRACKET	1
7213-PB	03DODGE,PASSENGER BRACKET	1
7213-DB	03DODGE,DRIVER BRACKET	1
12X3FTB	1/2 X 3 FINE THREAD BOLT	1
12X212FTB	1/2 X 2 1/2 FINE THRD BOLT	1
12X112FTB	1/2 X 1 1/2 FINE THRD BOLT	1
38X114FTB	3/8 X 1 1/4 FINE THD/GRD 8	4
516X114X134U	5/16 X 1 1/4 X 1 3/4 U-BT R	2
140629	EB6 STUD BAG - P932/140629	4
142121	ES24 SLEEVE/402087 1.38"	1

ITEM#	DESCRIPTION	QTY
81004	TAPERED SLEEVE, 1/2" I.D.	1
12FTN	1/2-20 FINE N/I LOCK NUT	3
38FTN	3/8-24 FINE N/I LOCK NUT	4
516CTN	5/16-18 COARSE N/I LOCK NUT	4
12SAEW	1/2 SAE WASHER	6
38SAEW	3/8 SAE WASHER	8
516SAEW	5/16 SAE WASHER	8
HSS	HYDRO SHOCK DECAL	2
B10RS	RED BOOT	2
BTIE	RED BOOT TIE	2
HOURLASS 5/8	SHOCK BUSHING	4

### Installation:

1. Park the vehicle on flat level ground & set the emergency brake.
2. Turn the tires / wheels to a straight forward position.
3. Remove the OEM stabilizer from the OEM axle bracket & draglink.
4. Install the new Skyjacker passenger side bracket to the OEM steering stabilizer mount on the axle using the supplied 1/2" x 3" fine thread bolt, washers, & nut. **Note:** Be sure to install the 1.38" anti-crush sleeve inside the OEM mount (Part # 142121-See Photo # 1)
5. Mark & drill the two lower mounting holes to 3/8". Once drilled, install the supplied 3/8" x 1 1/4" fine thread bolts, washers, & nuts. (See Photo # 2)
6. Install the new Skyjacker driver side bracket to the mounting hole in the bottom of the coil spring mount using the supplied 1/2" x 1 1/2" fine thread bolt, washers, & nut. (See Arrow in Photo # 3) Once installed, mark & drill the two lower holes as in Step # 5. Install using the supplied 3/8" x 1 1/4" fine thread bolts, washers, & nuts.
7. Install the tapered sleeve (Part # 81004) into the OEM mount on the drag link. Install the new Skyjacker main bracket at this location using the supplied 1/2" x 2 1/2" fine thread bolt, 5/16" x 1 1/4" x 1 3/4" u-bolts, washers, & nut. (See Photo # 4)
8. Install the new double ended studs to each bracket. These studs will mount to the top of the outer brackets & to the bottom of the main bracket. Slide the new Skyjacker shock boots over the shafts of the new Skyjacker steering stabilizers & attach with the supplied boot ties. Install the bushings into each end of the new steering stabilizers & attach to the studs of each bracket & tighten. (See Photo # 5)
9. Cycle steering left to right & check all parts for adequate clearance. Retighten all hardware after the first 100 miles.



Photo # 1



Photo # 2



Photo # 3



Photo # 4



Photo # 5



Photo # 6



## *Jesus Christ Died For You.*

John 3:16

For God so loved the world that He gave His only Son, so that everyone who believes in Him should not perish, but have everlasting life.  
Romans 3:23

For all have sinned; all fall short of God's glorious standard.  
Ephesians 2:8

God saved you by his special favor when you believed. And you can't take credit for this; it is a gift from God.  
Psalms 18:2

The Lord is my Rock, my fortress, and my savior; my God is my Rock, in whom I find protection. He is my shield, the strength of my salvation, and my stronghold.  
Romans 10:9-10

That if you shall confess with thy mouth the Lord Jesus, and shall believe in your heart that God hath raised him from the dead, you shall be saved. For with the heart man believeth unto righteousness; and with the mouth confession is made unto salvation.

Pray This Simple Prayer:

God, I come to You admitting I have sinned against You and I need you to take control of my life. The Bible says anyone who calls on the name of the Lord will be saved. I am calling on You, Jesus. I ask that You come live in my heart and be the Lord over my life today. I do believe You died on the cross for me and came back to life to give me life! Thank You, Lord Jesus for a new life in You!

Now, go and tell somebody about your new life in Jesus, get a Bible, begin to read it, and go to a Bible believing church.

If you would like someone to pray with you, call Kenneth Copeland Ministries anytime at 800-600-7395.

To listen to commercial free Christian radio on the web, go to [www.887fm.org](http://www.887fm.org)

## *Jesús murió por ti.*

Juan 3:16

“Porque tanto amó Dios al mundo, que dio a su Hijo unigénito, para que todo el que cree en él no se pierda, sino que tenga vida eterna.”  
Romanos 3:23

“Pues todos han pecado y están privados de la gloria de Dios.”  
Efesios 2:8

“Porque por gracia ustedes han sido salvados mediante la fe; esto no procede de ustedes, sino que es el regalo de Dios.”  
Salmos 18:2

“El Señor es mi roca, mi amparo, mi libertador; es mi Dios, el peñasco en que me refugio. Es mi escudo, el poder que me salva, ¡mi más alto escondite!”  
Romanos 10:9-10

“9 Que si confi esas con tu boca que Jesús es el Señor, y crees en tu corazón que Dios lo levantó de entre los muertos, serás salvo. 10 Porque con el corazón se cree para ser justifi cado, pero con la boca se confi esa para ser salvo.”

Ahora dí esta simple oración:

Dios, vengo a Ti y admito que he pecado contra Ti, necesito que tomes el control de mi vida. La Biblia dice que todo aquel que invoca el nombre del Señor escapará con vida. En este momento yo clamo ante Ti, Jesús; te pido que vengas a vivir en mi corazón y que tomes el control de mi vida. ¡Yo creo que tu moriste en la cruz y resucitaste para darme vida! ¡Gracias Señor Jesús, por una nueva vida que tengo en Ti! Amen.

Ahora ve y dile a alguien sobre la nueva vida que tienes en Cristo. Compra una Biblia y empieza a leerla. Busca una Iglesia que cree en la Biblia y hazte parte de esa Iglesia.

Si te gustaría orar con alguien, puedes llamar a este número 800-600-7395

Puedes ir a este sitio de Internet para escuchar música Cristiana sin anuncios, [www.887fm.org](http://www.887fm.org)

**Check out our favorite ministries at:**

**[www.innministries.org](http://www.innministries.org)**

**[www.familychurch.org](http://www.familychurch.org)**

**[www.kcm.org](http://www.kcm.org)**

