

JEEP®  
DUAL STABILIZER KIT  
INSTALLATION INSTRUCTIONS  
Kit #: 7219



Part #: 7009	Part #: 7119
1 - 7400WS Stabilizer	1 - 7900WS Stabilizer
2 - Hourglass 5/8" Bushings	2 - 83161 Mounting Brackets
1 - 142121 Sleeve (51792)	4 - Stem Bushings
1 - P837 Tapered Stud Bag	2 - 142120 Washer/Nut Packs
1 - Boot & Boot Tie	2 - 5/16" x 1" x 2 1/4" U-bolts, Nuts & Washers
	2 - 5/16" x 1 1/4" x 2 1/4" U-bolts, Nuts & Washers
	1 - Boot & Boot Tie

1. Place wheels in straight forward position.
  2. Remove OEM Steering Stabilizer. Install NEW Stabilizer in place using hardware provided.
  3. To install 7119 Stabilizer, place boot onto stabilizer, but **do not** secure boot with boot tie at this time.
  4. Install both brackets onto each end of stabilizer using bushing & washer packs provided.
  5. Pull the stabilizer rod out EXACTLY half-way out. Stabilizer must be kept out exactly half-way during installation.
  6. Mount stabilizer in place (refer to photo). Install U-bolts (5/16" x 1 1/4" x 2 1/4" around track bar and 5/16" x 1" x 2 1/4" around tie rod assembly), but **do not** tighten yet.
- NOTE: Be sure the passenger bracket is located directly below the tie rod clamp (see arrow below.)** After brackets are in position, tighten the U-bolts.
7. Turn wheels fully to the left & right to make sure stabilizer is adjusted properly (refer to step #5.)
  8. Place boot tie around boot & secure.

