



2005 Ford Super Duty Heavy-Duty Sway Bar Installation Instructions FSB550

www.skyjacker.com

1. Park the vehicle on level ground, set the emergency brake, and block the rear tires.
2. Locate the factory front sway bar, found on the front of the vehicle in front of the axle. Disconnect the sway bar from the sway bar links on the axle as shown in Photo below.
3. Disconnect the sway bar mounting brackets from the frame and remove sway bar.
4. Locate the new Heavy-Duty sway bar. Install the new polyurethane bushings on to the new sway bar. Slide the factory frame brackets onto new polyurethane bushings and attach new sway bar to the frame.
5. Attach new sway bar to the sway bar links on the axle. Be sure to retighten all bolts after the first 100 miles.

Seat Belts Save Lives, Please Wear Your Seat Belt.

