



www.skyjacker.com

2003 Dodge IFS 1500 4x4 Class II Lateral Strut Bars Part # LCSB260

<u>Part #</u>	<u>Description</u>	<u>Quantity</u>
D260KBF-S	DODGE 02,KICKER TAB - FRONT	2
D260KBRD-S	DODGE 02,KICK BRKT,REAR DRIVER	1
D260KBRP-S	DODGE 02,KICK BRKT,REAR PASSENGER	1
C966KB-S	DODGE LATERAL STRUT BAR	2
12X4FTB	1/2 X 4 FINE THREAD BOLT	4
12FTN	1/2-20 FINE N/I LOCK NUT	4
12SAEW	1/2 SAE WASHER	8
SP2099-BK	COMP STRUT BUSHING	8
SSJEEPRPU	SPRG SLEEVE DODGE	4

With vehicle on flat level ground set the emergency brake and block the rear tires.

1. Attach front kicker brace bracket over the 5/8" bolt on the rear cross member as shown in Photo #1.
2. Remove the two rear factory bolts from the transmission cross member and install the rear kicker brace bracket. Install bushings and sleeves into the new kicker bars. (See Photo #47). Attach the kicker bars to the new brackets using the 1/2" x 4" fine thread bolts, washers, and nuts. (See Photo #2).
3. Check all hardware for proper installation. Re-tighten all bolts after the first 100 miles.



Photo #1
Passenger Side Shown



Photo #2

Seat Belts Save Lives, Please Wear Your Seat Belt.