



Double Disconnect Sway Bar End Links Installation Instructions Part # SBE120/124/320

1. Remove the sway bar end link's lower bolt at the axle housing & the upper nut on both sides. (See Picture # 1)
2. The new end link mounting bracket should be mounted to the bottom of the sway bar with the bolt pointing up through the sway bar & the nut & washer applied on top. (See Picture # 2)
3. Apply lithium grease to the metal sleeves & insert the metal sleeves into the end link eyes. The top 1/2" x 2 1/2" bolt connecting the bracket to the end link must be installed with the nut to the outside of the vehicle to provide adequate clearance to the frame. Install the new double disconnect end links on the inboard side of the axle bracket. (See Picture # 3)



Picture #1
I-SBE120/124 REV2 8-10



Picture #2



Picture #3



Double Disconnect Sway Bar End Links Installation Instructions Part # SBE120/124/320

1. Remove the sway bar end link's lower bolt at the axle housing & the upper nut on both sides. (See Picture # 1)
2. The new end link mounting bracket should be mounted to the bottom of the sway bar with the bolt pointing up through the sway bar & the nut & washer applied on top. (See Picture # 2)
3. Apply lithium grease to the metal sleeves & insert the metal sleeves into the end link eyes. The top 1/2" x 2 1/2" bolt connecting the bracket to the end link must be installed with the nut to the outside of the vehicle to provide adequate clearance to the frame. Install the new double disconnect end links on the inboard side of the axle bracket. (See Picture # 3)



Picture #1
I-SBE120/124 REV2 8-10



Picture #2



Picture #3