



www.skyjacker.com

05-11 Ford Super Duty Front Track Bar Bracket Installation Instructions



BILL OF MATERIAL

<u>PART#</u>	<u>DESCRIPTION</u>	<u>QTY</u>
916X3FTB	9/16 X 3 FINE THREAD BOLT	3
916FTN	9/16-18 NYLON INSERT LOCKNUT	3
916SAEW	9/16 SAE WASHERS	6
D260PSS-S	CRUSH SLEEVE	3

Installation:

1. Park the vehicle on flat level ground, set the emergency brake, & block the rear tires.
2. Raise the vehicle & support the frame rails using jack stands. Support the front end using a floor jack.
3. Disconnect the track bar from the OEM track bar bracket using a 1 3/16" socket & remove the OEM track bar bracket. (See Photo # 1)
4. Attach the new Skyjacker track bar bracket to the OEM location on the cross member using the 9/16" X 3" fine thread bolts, washers, & nuts. **Note:** Be sure to use the three .938" long anti-crush spacers between the front of the bracket & the cross member. Do not tighten at this time. (See Photo # 2)
5. Attach the new Skyjacker track bar bracket to the frame using the OEM hardware. Torque all track bar bracket bolts to 129 Ft. Lbs.
6. Attach the track bar to the new Skyjacker track bar bracket using the OEM hardware. (See Photo # 3)
7. After the first 100 miles, re-torque all bolts.



Photo # 1



Photo # 2



Photo # 3

Seat Belts Save Lives, Please Wear Your Seat Belt!