

TRANSFER CASE LOWERING KIT INSTALLATION INSTRUCTIONS

Kit #: TCL15, TCL35, TCL45



1. Place floor jack under the transfer case skid plate, and raise jack enough to put a small amount of pressure on the plate.
2. Loosen the nuts in the center of the skid plate.
3. Remove the outer skid plate bolts along the frame rails.
4. Lower the floor jack and skid plate approximately 3" to allow the installation of the new spacers.

NOTE: There are only 2 on each side of the TCL15 & TCL45.

5. Insert the spacers between the skid plate and the frame.
6. Put a flat washer on the bolt and install bolt through the plate and tighten firmly. Repeat this process with all the the bolts and tighten firmly.

NOTE: There are only 4 spacers on the TCL15 & TCL45.

7. Remove floor jack and retighten all nuts in the center of the skid plate.*

* This step does not apply to the TCL15.

