

## Installation Instructions

P/N 42739 (chrome) - P/N 42739G (bronze)

P/N 42739K (black) - P/N 42739S (silver)

### Step 1

Clean the top of the factory Brake Fluid Cap Cover with alcohol to remove any dirt oil or contaminants.

### Step 2


Peel the backing film off the double sided tape. Place the cap cover onto the factory cap and press firmly to set.

### Step 3

For all other Cap Covers, place the cap cover onto the factory cap and press firmly to install until the tabs engage fully around the stock cap.

**ATTENTION:** Do not use harsh chemicals to clean covers.

If you have any difficulties or questions regarding the installation of this part, contact the Spectre Performance Technical Department by email - [Tech@spectreperformance.com](mailto:Tech@spectreperformance.com) or by phone 1-909-673-9800 Monday thru Friday 6:00am to 2:00pm PST.

 **WARNING** This product can expose you to a chemical or chemicals known to the State of California to cause cancer and birth defects or other reproductive harm.