

# 11107

03-06 GM

**TRUCKS & SUV's**



Corona, California

[www.trexbillet.com](http://www.trexbillet.com)

# 11107

03-06 GM

**TRUCKS & SUV's**

## **03-06 GM Trucks & SUV's**

### **Center Console Armrest Trim**

**TOOLS REQUIRED:**

Alcohol/Clean Rag

**PARTS LIST:**

1 T1 Series Center Console Armrest Trim

**Step 1**

Clean the area where the Trim Plate will be installed with alcohol and a clean rag. Test fit the trim plate. Remove the plastic backing on the adhesive on the back of the Center Console Armrest Trim.

**Step 2**

Position the Center Console Armrest Trim on top of the factory center console. Press down on the Center Console Armrest Trim to ensure the adhesive backing adheres to the factory center console.