



25708

03-06 HONDA
ELEMENT
BUMPER INSERT

25708

03-06 HONDA
ELEMENT
BUMPER INSERT

03-06 HONDA ELEMENT
BUMPER INSERT

Tools Required:

Drill or Screw Gun
Long Reach Phillips Bit

Hardware / Parts Included:

1 Bumper Billet (12 Bars)
4 #8 x 1" Screws (#6 Head)
4 #8 U-Nuts

Read and understand instructions before attempting installation

Step 1

The cross bars in the bumper opening can be removed from the bumper opening but is not necessary. Cut the cross bars out of the opening if desired. File the edges smooth.

Step 2

Center the billet insert in the bumper opening. Make a note where the mounting tabs on the billet insert align to the bumper opening. Remove the billet insert. Slide a U-nut over the rear edge of the opening at each mounting bracket. Hold the billet insert firmly in place. Using a drill gun and extended Phillips bit, install the #8 screws through the U-nut and into the plastic bumper opening. ***Thank you for purchasing a T-Rex Billet Grille. 1/28/04***