

T-REX

Billet Grilles

25799

**05-06 INFINITI
G-35 SEDAN**

25799

**05-06 INFINITI
G-35 SEDAN**

BUMPER INSERT

Tools Required:

Phillip Screwdriver


Hardware / Parts List:

2 Bumper Insert (9 Bars Each)
4 #8 x 1 Screws (#6 Head)
4 #8 U-Nuts
4 2" Flange Brackets

Read and understand instructions before attempting installation

Step 1

Remove the top grille to install the bumper inserts. Here is how you remove the factory grille. Remove the four plastic fasteners along the top using a Phillips screwdriver. There are two black plastic retaining fasteners on each end of the grille. Use a slotted screwdriver to twist the fasteners; Pull the grille forwards and release the molded clips along the bottom of the grille. Push the grille from behind to remove.



Step 2

Slide the U-nuts onto the flange brackets. Center one of the billet insert into the opening. Insert two of the screws into the tabs welded to the rear of the billet insert. From behind the mesh, install a flange bracket onto the screws. Tighten the hardware until the billet is held firmly in place. Repeat this process on the other billet. Re-install the factory grille onto the vehicle.

Thank you for purchasing your T-Rex billet grille.

T-Rex Truck Products Inc. 6/30/06